

ENGINE CONTROL SYSTEM

SECTION **EC**

EC

CONTENTS

CD20T	
PRECAUTIONS AND PREPARATION	3
Special Service Tools	3
Engine Fuel & Emission Control System	4
Precautions	5
ENGINE AND EMISSION CONTROL OVERALL SYSTEM	7
Engine Control Module Component Parts Location.....	7
Circuit Diagram	9
System Diagram	10
Vacuum Hose Drawing	11
System Chart	12
ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION	13
Glow Control System	13
Fuel Injection System	13
Fuel Injection Timing System	16
Air Conditioning Cut Control	18
Cooling Fan Control.....	18
CRANKCASE VENTILATION SYSTEM	19
Description	19
Blow-by Control Valve	19
Ventilation Hose.....	19
INJECTION NOZZLE	20
Removal and Installation	20
Test and Adjustment.....	20
ELECTRONIC FUEL INJECTION PUMP	22
Removal	22
Installation	23
Disassembly and Assembly.....	24

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION	25
DTC and MI Detection Logic	25
Diagnostic Trouble Code (DTC)	25
Malfunction Indicator (MI)	26
CONSULT-II.....	30
TROUBLE DIAGNOSIS — Introduction	36
Introduction	36
Diagnostic Worksheet	37
TROUBLE DIAGNOSIS — Work Flow	38
Work Flow	38
Description for Work Flow	39
TROUBLE DIAGNOSIS — Basic Inspection	40
Basic Inspection.....	40
TROUBLE DIAGNOSIS — General Description ..	42
Diagnostic Trouble Code (DTC) Chart	42
Symptom Matrix Chart	50
CONSULT-II Reference Value in Data Monitor Mode	53
Major Sensor Reference Graph in Data Monitor Mode	54
ECM Terminals and Reference Value.....	55
TROUBLE DIAGNOSIS FOR POWER SUPPLY	62
Main Power Supply and Ground Circuit	62
TROUBLE DIAGNOSIS FOR DTC 12	65
Mass Air Flow Sensor (MAFS)	65
TROUBLE DIAGNOSIS FOR DTC 13	69
Engine Coolant Temperature (ECT) Sensor	69
TROUBLE DIAGNOSIS FOR DTC 14	73
Vehicle Speed Sensor (VSS)	73
TROUBLE DIAGNOSIS FOR DTC 15	76
Control Sleeve Position Sensor (CSPS)	76

TROUBLE DIAGNOSIS FOR DTC 18	80	TROUBLE DIAGNOSES FOR DTC 83, 98	123
Electric Governor	80	Glow Control System	123
TROUBLE DIAGNOSIS FOR DTC 21	85	TROUBLE DIAGNOSES FOR DTC 85	131
Injection Timing Control Valve.....	85	Air Conditioner Cut Control.....	131
TROUBLE DIAGNOSIS FOR DTC 31, 82, 84, 91, 93	90	TROUBLE DIAGNOSES FOR DTC 86	134
Engine Control Module (ECM).....	90	EGRC-Solenoid Valve	134
TROUBLE DIAGNOSIS FOR DTC 28	91	TROUBLE DIAGNOSES FOR DTC 87	141
Cooling Fan (Overheat)	91	Brake Switch	141
TROUBLE DIAGNOSIS FOR DTC 34	101	TROUBLE DIAGNOSES FOR DTC 92	145
Needle Lift Sensor (NLS).....	101	ECCS-D Relay	145
TROUBLE DIAGNOSIS FOR DTC 36	104	TROUBLE DIAGNOSES FOR DTC 97	146
Fuel Cut Solenoid Valve	104	MI & Data Link Connectors	146
TROUBLE DIAGNOSIS FOR DTC 42	108	TROUBLE DIAGNOSES FOR NON-DETECTABLE ITEMS	149
Fuel Temperature Sensor (FTS)	108	Start Signal	149
TROUBLE DIAGNOSIS FOR DTC 43	112	SERVICE DATA AND SPECIFICATIONS (SDS)	151
Accelerator Position Sensor & Switch	112	General Specifications	151
TROUBLE DIAGNOSIS FOR DTC 47	119	Injection Nozzle.....	151
Crankshaft Position Sensor (TDC)	119	Inspection and Adjustment	151

When you read wiring diagrams:





- Read GI section, “HOW TO READ WIRING DIAGRAMS”.
- See EL section, “POWER SUPPLY ROUTING” for power distribution circuit.
- See EL section for NATS information and wiring diagram.

When you perform trouble diagnoses, read GI section, “HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES” and “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT”.

For clarification of system component abbreviations and terminology read GI section “SAE J1930 TERMINOLOGY LIST”.

Special Service Tools

X: Applicable
—: Not applicable

Tool number Tool name	Description	
KV11289004 Nozzle cleaning kit ① KV11290012 Box ② KV11290110 Brush ③ KV11290122 Nozzle oil sump scraper ④ KV11290140 Nozzle needle tip cleaner ⑤ KV11290150 Nozzle seat scraper ⑥ KV11290210 Nozzle holder ⑦ KV11290220 Nozzle hole cleaning needle	 <p>NT296</p>	X
KV11292010 Nozzle centering device	 <p>NT293</p>	X
KV11100300 No. 2-4 injection nozzle holder socket	 <p>NT563</p>	X
KV119E0030 No. 1 injection nozzle holder socket	 <p>NT648</p>	X

Engine Fuel & Emission Control System

ECM (ECCS-D control module)

- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.
- When ECM is removed for inspection, make sure to ground the ECM mainframe.

WIRELESS EQUIPMENT





- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
 - 1) Keep the antenna as far as possible away from the ECM.
 - 2) Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - 3) Adjust the antenna and feeder line so that the standing-wave ratio can be kept small.
 - 4) Be sure to ground the radio to vehicle body.

BATTERY

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.

ELECTRONIC FUEL INJECTOR PUMP

- Do not disconnect pump harness connectors with engine running.
- Do not disassemble or adjust electronic fuel injection pump, except for the following parts.
 - Camshaft position sensor (pump)
 - Injection timing control valve
 - Fuel cut solenoid valve



ECM PARTS HANDLING


- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble No. 1 injection nozzle (built-in needle lift sensor).
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor (TDC).

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.


ECM HARNESS HANDLING

- Connect ECM harness connectors securely. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECM system malfunction due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harnesses dry.
- Before removing parts, turn off ignition switch and then disconnect battery ground cable.




Precautions


- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.




- When connecting ECM harness connector, open the ports on harness connector, then meet the ports with the pins on the ECM as shown. Push slider on harness until it stops.



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.




- Before replacing ECM, perform Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-CD-55.




- If MI illuminates or blinks irregularly during engine running, water may have accumulated in fuel filter. Drain water from fuel filter. If this does not correct the problem, perform specified trouble diagnostic procedures.
- After performing each TROUBLE DIAGNOSIS, perform "OVERALL FUNCTION CHECK" or "DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE". The DTC should not be displayed in the "DTC CONFIRMATION PROCEDURE" if the repair is completed. The "OVERALL FUNCTION CHECK" should be a good result if the repair is completed.

Precautions (Cont'd)





- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



Engine Control Module Component Parts Location




Engine Control Module Component Parts Location (Cont'd)




NEF768


Circuit Diagram



System Diagram




Vacuum Hose Drawing



- ① EGRC-solenoid valve to EGR valve
- ② EGRC-solenoid valve to air duct
- ③ EGRC-solenoid valve to vacuum pump


Refer to “System Diagram” on previous page for vacuum control system.

System Chart



Glow Control System

SYSTEM DESCRIPTION



When coolant temperature is lower than 75°C (167°F):

- Ignition switch ON
After the ignition switch has been turned to ON, the glow relay turns ON for a period of time depending on the engine coolant temperature, allowing current to flow through the glow plugs.
- Starting
After starting the engine, current will flow through the glow plugs for 300 seconds, or until the coolant temperature exceeds 50°C (122°F).



Fuel Injection System

SYSTEM DESCRIPTION

Three types of fuel injection control are provided to accommodate the engine operating conditions; normal control, idle control and start control. The ECM determines the appropriate fuel injection control. Under each control, the amount of fuel injected is compensated to improve engine performance. The ECM performs duty cycle control on the electric governor (built into the fuel injection pump) according to sensor signals to compensate the amount of fuel injected to the preset value.

START CONTROL

Input/output signal line




When starting, the ECM adapts the fuel injection system for the start control. The amount of fuel injected at engine starting is a preset program value in the ECM. The program is determined by the engine speed and engine coolant temperature. For better startability under cool engine conditions, the lower the coolant temperature becomes, the greater the amount of fuel injected. The ECM ends the start control when the engine speed reaches a coolant temperature dependent value.

Fuel Injection System (Cont'd)

IDLE CONTROL



Input/output signal line



When the ECM determines that the engine speed is at idle, the fuel injection system is adapted for the idle control. The ECM regulates the amount of fuel injected corresponding to changes in load applied to the engine to keep engine speed constant. During the first 270s after a cold start, the ECM also provides the system with a fast idle control in response to the engine coolant temperature.


NORMAL CONTROL

Input/output signal line




The amount of fuel injected under normal driving conditions is determined according to sensor signals. The crankshaft position sensor (TDC) detects engine speed and the accelerator position sensor detects accelerator position. These sensors send signals to the ECM.

The fuel injection data, predetermined by correlation between various engine speeds and accelerator positions, are stored in the ECM memory, forming a map. The ECM determines the optimal amount of fuel to be injected using the sensor signals in comparison with the map.

Fuel Injection System (Cont'd)**FUEL TEMPERATURE COMPENSATION****Input/output signal line**

The amount of fuel leaking at or around high-pressure parts inside the fuel injection pump varies with fuel temperature and engine speed. This will result in a difference between the target amount of fuel injected and the actual amount. The ECM compensates for the actual amount depending on the signal from the fuel temperature sensor, the control sleeve position sensor and the crankshaft position sensor.

DECELERATION CONTROL**Input/output signal line**

The ECM cuts power supply delivery to the electric governor during deceleration for better fuel efficiency. The ECM determines the time of deceleration according to signals from the accelerator sensor and camshaft position sensor (PUMP).



Fuel Injection Timing System

SYSTEM DESCRIPTION

The fuel injection timing system determines the optimal fuel injection timing, based on engine speed, injection quantity, engine coolant temperature and atmospheric pressure. The timing is formed by a basic value (Basic Control) and two correction values. By performing a duty cycle signal on the timing control valve, the ECM allows the valve to provide optimal injection timing. The ECM also performs feedback control on the timing control valve using the signal from the needle lift sensor which detects the actual fuel injection timing.



BASIC CONTROL

Input/output signal line



The optimal fuel injection timing data, predetermined in proportion to engine speeds and amount of fuel injected, are stored in the ECM memory. The ECM uses the data to control the fuel injection timing.

HIGH ALTITUDE COMPENSATION





For better drivability in high altitude areas, the fuel injection timing is advanced and the fuel quantity is reduced according to the atmospheric pressure.

Fuel Injection Timing System (Cont'd)

ENGINE COOLANT TEMPERATURE COMPENSATION (During driving)



Input/output signal line



For better exhaust efficiency under cool engine conditions, the fuel injection timing is controlled within a compensation range depending on the engine speed, engine coolant temperature and amount of fuel injected.

ENGINE COOLANT TEMPERATURE COMPENSATION (When starting)


Input/output signal line



For better startability under cool engine conditions, the fuel injection timing is compensated according to the engine coolant temperature.

Air Conditioning Cut Control

INPUT/OUTPUT SIGNAL LINE




SYSTEM DESCRIPTION

This system improves acceleration when the air conditioner is used. When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds. When engine coolant temperature becomes excessively high, the air conditioner is turned off. This continues until the coolant temperature returns to normal.


Cooling Fan Control


INPUT/OUTPUT SIGNAL LINE



The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, and air conditioner ON signal. The control system has 3-step control [OFF/LOW/HIGH].


Operation






Description

- In this system blow-by gas is sucked into the air inlet pipe through the control valve after oil separation by the oil separator in the rocker cover.



Blow-by Control Valve

- Check control valve for clogging and abnormalities.





Ventilation Hose

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.

CAUTION:

- Do not disassemble injection nozzle assembly. Entrust disassembly or adjustment to BOSCH service shop.
- Plug flare nut with a cap or rag so that no dust enters the nozzle.



Removal and Installation

1. Remove fuel injection tube and spill tube.
2. Remove injection nozzle assembly.
3. Install injection nozzle in the reverse order of removal.

Also remove gasket from nozzle end.

Injection nozzle to engine:

: 59 - 69 N·m (6.0 - 7.0 kg-m, 43 - 51 ft-lb)

Injection nozzle to tube:

: 22 - 25 N·m (2.2 - 2.5 kg-m, 16 - 18 ft-lb)

Spill tube:

: 39 - 49 N·m (4.0 - 5.0 kg-m, 29 - 36 ft-lb)

- a. Always clean the nozzle holes.
- b. Always use new injection nozzle gasket.
- c. Note that small washer should be installed in specified direction.
- d. Bleed air from fuel system.


Test and Adjustment

WARNING:


When using nozzle tester, be careful not to allow diesel fuel sprayed from nozzle to contact your hands or body, and make sure your eyes are properly protected with goggles.

INJECTION PRESSURE TEST

1. Install nozzle to injection nozzle tester and bleed air from flare nut.



Test and Adjustment (Cont'd)



2. Pump the tester handle slowly (one time per second) and watch the pressure gauge.
3. Read the pressure gauge when the injection pressure just starts dropping.

Initial injection pressure:


Used

14,423 - 15,651 kPa
(144.2 - 156.5 bar,
148 - 159 kg/cm², 2,091 - 2,269 psi)

New


15,000 - 16,000 kPa
(150.0 - 160.0 bar,
153 - 163 kg/cm², 2,175 - 2,320 psi)

Always check initial injection pressure using a new nozzle. If the pressure is not correct, replace nozzle assembly.




LEAKAGE TEST

1. Maintain the pressure at about 981 to 1,961 kPa (9.8 to 19.6 bar, 10 to 20 kg/cm², 142 to 284 psi) below initial injection pressure.
2. Check that there is no dripping from the nozzle tip or around the body.
3. If there is leakage, replace nozzle.



SPRAY PATTERN TEST


1. Check spray pattern by pumping tester handle one full stroke per second.
 - a. **If main spray angle is within 30 degrees as shown, injection nozzle is good.**
 - b. **It is still normal even if a thin stream of spray deviates from the main spray (pattern B).**
2. Test again and if spray pattern is not corrected, replace nozzle.



- | | | |
|---------------------------|-------------------|----------------------------------|
| ① Rear back cover | ④ Water connector | ⑦ Electronic fuel injection pump |
| ② Injection pump sprocket | ⑤ Bracket | ⑧ Key |
| ③ Injection pump bracket | ⑥ Bracket | |


Removal

1. Remove battery.
Disconnect electronic injection pump harness connectors.




2. Set No. 1 piston at TDC on its compression stroke.
TDC: Crankshaft pulley notch without painted mark
3. Remove fuel hoses (supply, return and spill) and injection tubes.
4. Remove air duct and injection pump timing belt cover.
5. Remove injection pump timing belt.
Refer to EM section ("Injection Pump Timing Belt").


Removal (Cont'd)



6. Remove injection pump sprocket with Tool.
 - Remove key from injection pump shaft and store safely.




7. Remove injection pump assembly.



Installation

1. Install key on injection pump shaft, then install injection pump sprocket.
2. Install injection pump timing belt.
Refer to EM section ("Injection Pump Timing Belt").
3. Adjust injection timing.
Refer to "Basic Inspection", EC-CD-40.
4. Install all parts removed.

Installation (Cont'd)



Disassembly and Assembly

CAUTION:

- Do not disassemble the parts not shown in the illustration above.
- Before installing injection timing control valve, apply a coat of diesel fuel to O-ring and its mating area. Insert injection timing control valve straight into bore in fuel pump body. After properly positioning injection timing control valve, visually check for fuel leaks.
- After assembling the parts, erase Diagnostic Trouble Code (DTC), and perform DTC CONFIRMATION PROCEDURE (or OVERALL FUNCTION CHECK).

DTC and MI Detection Logic

When a malfunction is detected for the first time, the malfunction (DTC) is stored in the ECM memory. The MI will light up each time the ECM detects a malfunction. However, if the same malfunction is experienced in two consecutive driving patterns and the engine is still running, the MI will stay lit up. For diagnostic items causing the MI to light up, refer to “Diagnostic Trouble Code (DTC) Chart”, EC-CD-42.

Diagnostic Trouble Code (DTC)

HOW TO READ DTC

The diagnostic trouble code can be read by the following methods.

- The number of flashes of the malfunction indicator in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 11, 13, 14, etc.
These DTCs are controlled by NISSAN.
- CONSULT-II Examples: “CRANK POS SEN (TDC)”, etc.
 - **Output of the trouble code warns that the indicated circuit has a malfunction. However, when using MI in Mode II there is no indication to determine whether the malfunction is still occurring or has occurred in the past and row returned to normal. CONSULT-II can identify the timing of a malfunctions and so use of CONSULT-II (if available) is recommended.**
 - **DTCs are stored up to a maximum of 7 items that have highest priority in each grouped DTC occurred at that time. A new entry of DTC can overwrite an existing entry with a lower priority if the DTC memory is full. If 7 DTCs are read, other remained DTCs can be read after the existing DTC item has been corrected and the DTC is erased.**

HOW TO ERASE DTC

The diagnostic trouble code can be erased by the following methods.

- ☑ Selecting “ERASE” in the “SELF-DIAG RESULTS” mode with CONSULT-II.
- ☒ Changing the diagnostic test mode from Diagnostic Test Mode II to Mode I twice. (Refer to “HOW TO SWITCH DIAGNOSTIC TEST MODES”.)
 - **If the battery terminal is disconnected, the diagnostic trouble code will be lost within 24 hours.**
 - **When you erase the DTC, using CONSULT-II is easier and quicker than switching the diagnostic test modes.**
 - **Erasing DTC is possible only when the ECM has recognised the DTC item is corrected. If erasing is not possible, turn the ignition switch to the “LOCK” position once. Wait for at least 5 seconds and then turn it “ON” (engine stopped) again.**

☑ HOW TO ERASE DTC (With CONSULT-II)

- If the ignition switch stays “ON” after repair work, be sure to turn ignition switch to the “LOCK” position once. Wait for at least 5 seconds and then turn it “ON” (Engine stopped) again.
- Turn CONSULT-II “ON” and touch “ENGINE”.
- Touch “SELF-DIAG RESULTS”.
- Touch “ERASE”. (The DTC in the ECM will be erased.)


<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th style="background-color: black; color: white;">SELECT SYSTEM</th></tr> <tr><td style="text-align: center;">ENGINE</td></tr> <tr><td style="text-align: center;">AIR BAG</td></tr> <tr><td style="text-align: center;">ABS</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table> <p>1. Touch “Engine”.</p>	SELECT SYSTEM	ENGINE	AIR BAG	ABS				<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th style="background-color: black; color: white;">SELECT DIAG MODE</th></tr> <tr><td style="text-align: center;">SELF DIAG RESULTS</td></tr> <tr><td style="text-align: center;">DATA MONITOR</td></tr> <tr><td style="text-align: center;">ACTIVE TEST</td></tr> <tr><td style="text-align: center;">ECU PART NUMBER</td></tr> <tr><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td></tr> </table> <p>2. Touch “SELF-DIAG RESULTS”.</p>	SELECT DIAG MODE	SELF DIAG RESULTS	DATA MONITOR	ACTIVE TEST	ECU PART NUMBER			<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2" style="background-color: black; color: white;">SELF DIAG RESULTS</th></tr> <tr><th colspan="2" style="background-color: black; color: white;">DTC RESULTS</th></tr> <tr><th style="width: 70%;"> </th><th style="width: 30%;">TIME</th></tr> <tr><td style="text-align: center;">CRANK POS SEN (TDC)</td><td style="text-align: center;">0</td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> <tr><td style="text-align: center;"> </td><td style="text-align: center;"> </td></tr> </table> <p>3. Touch “ERASE”. (The DTC in the ECM will be erased.)</p>	SELF DIAG RESULTS		DTC RESULTS			TIME	CRANK POS SEN (TDC)	0				
SELECT SYSTEM																												
ENGINE																												
AIR BAG																												
ABS																												
SELECT DIAG MODE																												
SELF DIAG RESULTS																												
DATA MONITOR																												
ACTIVE TEST																												
ECU PART NUMBER																												
SELF DIAG RESULTS																												
DTC RESULTS																												
	TIME																											
CRANK POS SEN (TDC)	0																											

C2SSE03

Diagnostic Trouble Code (DTC) (Cont'd)

HOW TO ERASE DTC (No Tools)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch to "LOCK" position once. Wait at least 5 seconds and then turn it "ON" again.
2. Change the diagnostic test mode from Mode II to Mode I twice. When changing modes, wait at least 2 seconds. (Refer to EC-CD-27.)



Malfunction Indicator (MI)

1. The malfunction indicator will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the malfunction indicator does not light up, refer to EL section ("WARNING LAMPS AND CHIME") or see EC-CD-27.
2. When the engine is started, the malfunction indicator should go off. If the lamp remains on, the on board diagnostic system has detected an engine system malfunction.

If MI illuminates or flashes irregularly after starting engine, water may have accumulated in fuel filter. Drain water from fuel filter.




ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The ON BOARD DIAGNOSTIC SYSTEM FUNCTION


The on board diagnostic system has the following three functions:

1. **BULB CHECK** : This function checks the MI bulb for damage (blown, open circuit, etc.).
2. **MALFUNCTION WARNING** : This is a usual driving condition. When a malfunction is detected, the MI will light up to inform the driver that a malfunction has been detected.
3. **SELF-DIAGNOSTIC RESULTS** : This function allows diagnostic trouble codes to be read.

Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES" on next page.

Condition		Diagnostic Test Mode I	Diagnostic Test Mode II
Ignition switch in "ON" position 	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	—

Malfunction Indicator (MI) (Cont'd) HOW TO SWITCH DIAGNOSTIC TEST MODES



Malfunction Indicator (MI) (Cont'd)

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MALFUNCTION INDICATOR on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to EL section (“WARNING LAMPS AND CHIME”) or see EC-CD-27.


DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MALFUNCTION INDICATOR	Condition
ON	When the malfunction is detected or the ECM’s CPU is malfunctioning. (The “MI Illumination” of the “DTC Chart”.) Refer to EC-CD-43.
OFF	No malfunction.

- These Diagnostic Trouble Code Numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, a diagnostic trouble code is indicated by the number of flashes of the MALFUNCTION INDICATOR as shown below.



Long (0.6 second) flashes indicate the number of ten digits, and short (0.3 second) flashes indicate the number of single digits. For example, the malfunction indicator flashes 4 times for 0.6 sec and then it flashes three times for about 0.3 sec. This indicates the DTC “43” and refers to the malfunction of the accelerator position sensor.

In this way, all the detected malfunctions are classified by their diagnostic trouble code numbers. The DTC “55” refers to no malfunction. (See DIAGNOSTIC TROUBLE CODE CHART, EC-CD-44.)

HOW TO ERASE DIAGNOSTIC TEST MODE II (Self-diagnostic results)

The diagnostic trouble code can be erased from the backup memory in the ECM when the diagnostic test mode is changed twice from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to “HOW TO SWITCH DIAGNOSTIC TEST MODES” on previous page.)

- If the battery terminal is disconnected, the diagnostic trouble code will be lost from the backup memory within 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.


SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION	0

C2SDR02

- If the MI blinks or “NATS MALFUNCTION” is displayed on “SELF-DIAG RESULTS” screen, perform self-diagnostic results mode with CONSULT-II using NATS program card (NATS-E940). Refer to EL section.
- Confirm no self-diagnostic results of NATS is displayed before touching “ERASE” in “SELF-DIAG RESULTS” mode with CONSULT-II.
- When replacing ECM, initialisation of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card (NATS-E940). Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialisation and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.

Malfunction Indicator (MI) (Cont'd)


RELATIONSHIP BETWEEN MI, DTC, CONSULT-II AND DRIVING PATTERNS



NEF764

- *1: When a malfunction is detected, MI will light up.
- *2: When a malfunction is detected for the first time, the DTC will be stored in ECM.
- *3: The DTC will not be displayed any longer after vehicle is driven 40 times without the same malfunction. (The DTC still remains in ECM.)


- *4: Other screens except SELF-DIAGNOSTIC RESULTS & DATA MONITOR (AUTO TRIG) cannot display the malfunction. DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.



CONSULT-II


CONSULT-II INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "CONSULT-II" to data link connector for CONSULT-II.
(Data link connector for CONSULT-II is located behind the fuse box cover.)



3. Turn on ignition switch.
4. Touch "START".
5. Touch "ENGINE".
6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.



CONSULT-II (Cont'd)

ENGINE CONTROL MODULE COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		Item	DIAGNOSTIC TEST MODE		
			SELF-DIAG-NOSTIC RESULTS	DATA MONITOR	ACTIVE TEST
ENGINE CONTROL MODULE COMPONENT PARTS	INPUT	Camshaft position sensor (PUMP) *1	X *2	X	
		Mass air flow sensor	X	X	
		Engine coolant temperature sensor	X	X	
		Control sleeve position sensor	X	X	X
		Fuel temperature sensor	X	X	
		Vehicle speed sensor	X	X	
		Accelerator position sensor	X	X	
		Accelerator position switch		X	
		Brake lamp switch	X *2	X	
		Crankshaft position sensor (TDC)	X	X	
		Needle lift sensor	X	X	
		Ignition switch (start signal)		X	
		Ignition switch (ON signal)		X	
		Air conditioner switch		X	
		Brake switch		X	
	Battery voltage		X		
	OUTPUT	Injection timing control valve	X	X	X
		Fuel cut solenoid valve	X	X	X
		Air conditioner relay		X	
		Glow relay		X	X
EGRC-solenoid valve			X	X	
Cooling fan relay			X	X	

X: Applicable

*1: Imaginary sensor, which produces secondary engine revolution signal using needle lift sensor pulse.

*2: CONSULT-II may not display, but self-diagnostic results are available with MI.

CONSULT-II (Cont'd)

SELF-DIAGNOSTIC MODE

Regarding items detected in "SELF-DIAG RESULTS" mode, refer to "Diagnostic Trouble Code (DTC) chart". (See EC-CD-28.)

DATA MONITOR MODE

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
CKPS•RPM (TDC) [rpm]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The engine speed computed from the crankshaft position sensor (TDC) signal is displayed. 	
CMPS•RPM - PUMP [rpm]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The engine speed computed from the camshaft position sensor (PUMP) signal is displayed. 	
COOLAN TEMP/S [°C] or [°F]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
VHCL SPEED SE [km/h] or [mph]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed sensor signal is displayed. 	
FUEL TEMP SEN [°C] or [°F]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The fuel temperature (determined by the signal voltage of the fuel temperature sensor) is displayed. 	
ACCEL POS SEN [V]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The accelerator position sensor signal voltage is displayed. 	
OFF ACCEL POS [ON/OFF]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the accelerator position switch signal. 	
C/SLEEV POS/S [V]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The control sleeve position sensor signal voltage is displayed. 	
BATTERY VOLT [V]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
START SIGNAL [ON/OFF]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the starter signal. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal.
AIR COND SIG [ON/OFF]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 	
BRAKE SW [ON/OFF]	<input type="radio"/>		<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the stio lamp switch. 	
BRAKE SW2 [ON/OFF]	<input type="radio"/>		<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the stio lamp switch 2. 	
IGN SW [ON/OFF]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch. 	
MAS AIR/FL SE [V]	<input type="radio"/>	<input type="radio"/>	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
ACT INJ TIMG [°]	<input type="radio"/>		<ul style="list-style-type: none"> The actual injection timing angle determined by the ECM (an approximate average angle between injection start and end from TDC) is displayed. 	
TARGET F/INJ [mm ³ /STROKE]	<input type="radio"/>		<ul style="list-style-type: none"> The target fuel injection quantity (determined by the ECM according to the input signal) is indicated. 	

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

CONSULT-II (Cont'd)

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
FUEL CUT S/V [ON/OFF]			<ul style="list-style-type: none"> ● The control condition of the fuel cut solenoid valve (determined by ECM according to the input signal) is indicated. ● OFF ... Fuel cut solenoid valve is not operating. ON ... Fuel cut solenoid valve is operating. 	<ul style="list-style-type: none"> ● When the fuel cut solenoid valve is not operating, fuel supply is shut off.
AIR COND RLY [ON/OFF]		○	<ul style="list-style-type: none"> ● The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 	
GLOW RLY [ON/OFF]		○	<ul style="list-style-type: none"> ● The glow relay control condition (determined by ECM according to the input signal) is displayed. 	
COOLING FAN [LOW/HI/OFF]		○	<ul style="list-style-type: none"> ● Indicates the control condition of the cooling fans (determined by ECM according to the input signal). ● LOW ... Operates at low speed. HI ... Operates at high speed. OFF ... Stopped. 	
EGRC SOL/V A [ON/OFF]			<ul style="list-style-type: none"> ● The control condition of the EGRC-solenoid valve (determined by ECM according to the input signal) is indicated. ● OFF ... EGRC-solenoid valve is not operating. ON ... EGRC-solenoid valve is operating. 	

CONSULT-II (Cont'd)

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
TARGET F/INJ	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Fix the target injection quantity using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Control sleeve position sensor
COOLING FAN	<ul style="list-style-type: none"> ● Ignition switch: ON ● Operate the cooling fan at "LOW", "HI" speed and turn "OFF" using CONSULT-II. 	Cooling fan moves at "LOW", "HI" speed and stops.	<ul style="list-style-type: none"> ● Harness and connector ● Cooling fan motor
FUEL CUT SOL/V	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
EGRC SOL/V A	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn solenoid valve "ON" and "OFF" with the CONSULT-II and listen to operating sound. 	Solenoid valve makes an operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Solenoid valve
GLOW RLY	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the glow relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Glow relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connector ● Fuel pump relay
INJ TIMING	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Retard the injection timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Adjust initial injection timing

CONSULT-II (Cont'd)


REAL TIME DIAGNOSIS IN DATA MONITOR MODE


CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):
 - The malfunction will be identified on the CONSULT-II screen in real time. In other words, DTC and malfunction item will be displayed at the moment the malfunction is detected by ECM.
 - DATA MONITOR can be performed continuously until a malfunction is detected. However, DATA MONITOR cannot continue any longer after the malfunction detection.
2. "MANU TRIG" (Manual trigger):
 - DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
 - DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

1. "AUTO TRIG"
 - While trying to detect the DTC by performing the "DTC CONFIRMATION PROCEDURE", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
 - While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. Inspect the circuit by gently shaking (or twisting) suspicious connectors, components and harness in the "DTC CONFIRMATION PROCEDURE". The moment a malfunction is found the DTC will be displayed. (Refer to GI section, "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".)
2. "MANU TRIG"
 - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.





Introduction



The engine has an ECM to control major systems such as fuel injection control, fuel injection timing control, glow control system, etc. The ECM accepts input signals from sensors and instantly drive the electronic fuel injection pump use the data to based on current ambient conditions. It is essential that both input and output signals are correct and stable. At the same time, it is important that there are no problems such as vacuum leaks, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than catastrophically. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not be sufficient to determine the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the “Work Flow” on the next page.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A “Diagnostic Worksheet” like the example on next page should be used.

Start your diagnosis by looking for “conventional” problems first. This will help troubleshoot driveability problems on a vehicle with an electronically controlled engine.



Work Flow








***1: If the incident cannot be duplicated, refer to GI section ("Incident Simulation Tests", "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT").**

***2: If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to "TROUBLE DIAGNOSIS FOR MAIN POWER SUPPLY AND GROUND CIRCUIT", EC-CD-62.**

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the “DIAGNOSTIC WORKSHEET” as shown on the next page.
STEP II	<p>Before confirming the concern, check and write down (print out using CONSULT-II) the Diagnostic Trouble Code (DTC), then erase the code. Refer to EC-CD-25.) The DTC can be used when duplicating the incident at STEP III & IV.</p> <p>Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The “Symptom Matrix Chart” will be useful. Refer to EC-CD-50.)</p>
STEP III	<p>Try to confirm the symptom and under what conditions the incident occurs.</p> <p>The “DIAGNOSTIC WORK SHEET” is useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.</p> <p>If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. Refer to GI section.</p> <p>If the malfunction code is detected, skip STEP IV and perform STEP V.</p>
STEP IV	<p>Try to detect the Diagnostic Trouble Code (DTC) by driving in (or performing) the “DTC CONFIRMATION PROCEDURE”. Check and read the DTC by using CONSULT-II.</p> <p>During the DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results.</p> <p>If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. Refer to GI section.</p> <p>In case the “DTC CONFIRMATION PROCEDURE” is not available, perform the “OVERALL FUNCTION CHECK” instead. The DTC cannot be displayed by this check, however, this simplified “check” is an effective alternative.</p> <p>The “NG” result of the “OVERALL FUNCTION CHECK” is the same as the DTC detection.</p>
STEP V	<p>Take the appropriate action based on the results of STEP I through IV.</p> <p>If the malfunction code is indicated, proceed to specific TROUBLE DIAGNOSIS FOR DTC.</p> <p>If the normal code is indicated, proceed to the BASIC INSPECTION. Refer to EC-CD-40. Then perform inspections according to the Symptom Matrix Chart. Refer to EC-CD-50.</p>
STEP VI	<p>Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) “Harness Lay-outs”.</p> <p>Gently shake the related connectors, components or wiring harness with CONSULT-II set in “DATA MONITOR (AUTO TRIG)” mode.</p> <p>Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-CD-55.</p> <p>The “DIAGNOSTIC PROCEDURE” in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the DIAGNOSTIC PROCEDURE. For details, refer to GI section (“Circuit Inspection”, “HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT”).</p> <p>Repair or replace the malfunctioning parts.</p>
STEP VII	<p>Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer’s initial complaint.</p> <p>Perform the “DTC CONFIRMATION PROCEDURE” and confirm the normal code (Diagnostic trouble code No. 55) is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one.</p> <p>Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM. (Refer to EC-CD-25.)</p>



Basic Inspection

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied;

- Headlamp switch is off,
- Air Conditioner switch is off,
- Rear defogger switch is off,
- Steering wheel is in the straight-ahead position, etc.

A

BEFORE STARTING

1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for faulty connections
 - Vacuum hoses for splits, kinks, or faulty connections
 - Wiring for faulty connections, pinches, or cuts
3. Using priming pump, bleed air from fuel system. Refer to "Fuel Filter Check" in MA section.

B

CONNECT CONSULT-II TO THE VEHICLE.

Connect "CONSULT-II" to the data link connector for CONSULT-II and select "ENGINE" from the menu. Refer to EC-CD-30.

DOES ENGINE START?

Yes → Run engine for 10 minutes.

No → Turn ignition switch to the "LOCK" position, wait 5 seconds and then start engine. If engine fails to start, check diagnostic trouble code (DTC).

Run engine for 10 minutes.

C

CHECK IDLE SPEED.





Read engine idle speed in "DATA MONITOR" mode with CONSULT-II.
825 rpm ± 25 (in N position)

OR


Check idle speed using tachometer tester.
825 rpm ± 25 (in N position)

(Go to A on next page.)

Basic Inspection (Cont'd)



- D**
- CHECK INJECTION TIMING.**
1. Set No. 1 piston at TDC on its compression stroke.
TDC: Without painted mark
 2. Remove injection tubes and air bleeder on the back of injection pump.
 3. Set dial gauge so its indicator points to somewhere between 1.0 and 2.0 mm (0.039 and 0.079 in) on the scale.
 4. Turn crankshaft 2 turns clockwise and check that dial gauge indicates the same value again.
 5. Turn crankshaft counterclockwise about 100 degrees, then turn crankshaft slowly clockwise, and set dial gauge indicator to 0 mm at the position it stops.
 6. Turn crankshaft clockwise and set it at plunger lift timing mark using the mark on the crankshaft pulley.
plunger lift timing mark: Yellow painted mark
 7. Read plunger lift.
Plunger lift:
0.89 ± 0.08 mm (0.0350 ± 0.0031 in) at plunger lift timing mark
- When repeating the checking, start with step 5.



- NG
- E**
- Adjusting**
1. If plunger lift is not within the specified value, adjust by turning injection pump.
 - If indication is smaller than the specified value, turn pump body away from engine.
 - If indication is larger than the specified value, turn pump body towards engine.
 2. Tighten injection pump securing bolts and nuts.
Nut:
ⓘ : 20 - 25 N·m (2.0 - 2.6 kg-m, 15 - 18 ft-lb)
Bolt:
ⓘ : 25 - 35 N·m (2.6 - 3.6 kg-m, 18 - 26 ft-lb)
 3. Remove dial gauge and install air bleeder with new washer.
 4. Install injection tubes.
Flare nut:
ⓘ : 14 - 20 N·m (1.4 - 2.0 kg-m, 10 - 15 ft-lb)
 5. Bleed air from fuel system. Refer to "Water Draining, Fuel Filter Check and Replacement" of "ENGINE MAINTENANCE" in MA section.



Diagnostic Trouble Code (DTC) Chart

ENGINE RELATED ITEMS

Diagnostic trouble code No.	Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
12	Mass air flow sensor circuit (MASS AIR FLOW SEN)	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by the ECM.
13	Engine coolant temperature sensor circuit (COOLANT TEMP SEN)	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by the ECM.
14	Vehicle speed sensor circuit (VEHICLE SPEED SEN)	<ul style="list-style-type: none"> ● The almost 0 km/h (0 mph) signal from the sensor is detected by the ECM even when vehicle is being driven.
15	Control sleeve position sensor circuit (CONT SLEEV POS SEN)	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by the ECM. ● An incorrect voltage signal from the sensor is detected by the ECM during engine running.
18	Fuel injection feedback 2 (F/INJ F/B 2)	<ul style="list-style-type: none"> ● The fuel injection feedback system (consists of the ECM, electric governor and control sleeve position sensor) does not operate properly.
21	Fuel injection timing feedback (F/INJ TIMG F/B)	<ul style="list-style-type: none"> ● The fuel injection timing feedback system (consists of the ECM, fuel injection timing control valve and needle lift sensor) does not operate properly.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

- IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.
- RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.
- DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

- IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).
- RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).
- DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

—: Not applicable

Check Items (Possible Cause)	DTC Confirmation Procedure Quick Ref. *1	Overall Function Check *2	MI Illumination	Reference Page
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor 	IGN: ON	—	—	EC-CD-65
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor 	IGN: ON	—	Lighting up	EC-CD-69
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Vehicle speed sensor 	—	LIFTING	—	EC-CD-73
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Control sleeve position sensor 	RUNNING	—	Lighting up	EC-CD-76
<ul style="list-style-type: none"> ● Main power supply circuit (ECM terminals (23), (45), (68) and fuse ● Harness or connectors (Electric governor and control sleeve position sensor circuit) ● Electronic fuel injection pump ● ECM ● Electric governor 	RUNNING (DRIVING)	—	Lighting up	EC-CD-80
<ul style="list-style-type: none"> ● Harness or connectors (Injection timing control valve, Needle lift sensor and Crankshaft position sensor (TDC) circuit] ● Injection timing control valve ● Needle lift sensor ● Crankshaft position sensor ● Air in fuel line 	RUNNING (DRIVING)	—	Lighting up	EC-CD-85

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".
Details are described in each TROUBLE DIAGNOSIS FOR DTC.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.
In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".
When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

- During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.
- This is Quick Reference of "OVERALL FUNCTION CHECK".
Details are described in each TROUBLE DIAGNOSIS FOR DTC.

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

ENGINE RELATED ITEMS

Diagnostic trouble code No.	Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
28	Cooling fan (OVER HEAT)	<ul style="list-style-type: none"> ● An excessive high engine coolant temperature sensor signal is detected by the ECM. (Overheat)
31	ECM2 (ECM2)	<ul style="list-style-type: none"> ● ECM calculation function is malfunctioning.
34	Needle lift sensor circuit (NEEDLE LIFT SEN)	<ul style="list-style-type: none"> ● An incorrect signal from the sensor is detected by the ECM during engine running.
36	Fuel cut solenoid valve 1 (FUEL CUT S/V 1)	<ul style="list-style-type: none"> ● Fuel cut solenoid valve circuit is malfunctioning.
42	Fuel temperature sensor circuit (FUEL TEMP SENSOR)	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by the ECM.
43	Accelerator position sensor circuit (ACCEL POS SENSOR)	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by the ECM.
47	Crankshaft position sensor (TDC) [CRANK POS SEN (TDC)]	<ul style="list-style-type: none"> ● An incorrect signal from the sensor is detected by the ECM during engine running and cranking.
55	No failure (NO SELF DIAGNOSTIC FAILURE INDICATED)	No malfunction is detected by the ECM.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

- IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.
- RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.
- DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

- IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).
- RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).
- DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

—: Not applicable

Check Items (Possible Cause)	DTC Confirmation Procedure Quick Ref. *1	Overall Function Check *2	MI Illumination	Reference Page
<ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat ● Fan belt ● Engine coolant temperature sensor For more information, refer to "12 MAIN CAUSES OF OVERHEATING". (EC-CD-99)	—	IGN: ON (RUNNING)	Lighting up	EC-CD-80
<ul style="list-style-type: none"> ● ECM 	IGN: ON	—	Lighting up	EC-CD-90
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Needle lift sensor ● Air in fuel line ● Clogging No. 1 injection nozzle 	RUNNING	—	Lighting up	EC-CD-101
<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● Fuel cut solenoid valve 	RUNNING	—	Lighting up	EC-CD-104
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel temperature sensor 	IGN: ON	—	—	EC-CD-108
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Accelerator position sensor ● Accelerator position switch 	IGN: ON	—	Lighting up	EC-CD-112
<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Crankshaft position sensor (TDC) 	RUNNING	—	Lighting up	EC-CD-119
<ul style="list-style-type: none"> ● No failure 	—	—	—	—

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".

Details are described in each specific TROUBLE DIAGNOSIS FOR DTC.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.

In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

● During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.

● This is Quick Reference of "OVERALL FUNCTION CHECK".

Details are described in each specific TROUBLE DIAGNOSIS FOR DTC.

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

ENGINE RELATED ITEMS

Diagnostic trouble code No.	Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
82	Atmospheric pressure sensor *5 (—) *3	● An excessively high or low voltage from the sensor is detected by the ECM.
83	Glow relay circuit (GLOW RELAY)	● Glow relay circuit is open or shorted.
84	ECM (—)*3	● ECM reference voltage (2.5V) is excessively high or low.
85	Air conditioner relay circuit (—)*3	● Air conditioner relay circuit is shorted.
86	EGRC-solenoid valve A (EGR SYS)	● EGRC-solenoid valve A is open or shorted.
87	Brake switch circuits (—)*3	● Brake switch circuits are open or shorted.
91	ECM (—)*3	● ECM version number or switching function is not plausible.
92	ECCS-D relay circuit (—)*3	● ECCS-D relay shut-off time is too late.
93	Ignition switch "ON" signal circuit (—)*3	● Ignition switch "ON" signal evaluation circuit in ECM is malfunctioning.
94	Injection timing control valve circuit (INJ TIMING CONT/V)	● Injection timing control valve circuit is open or shorted.
96	Camshaft position sensor (PUMP)*4 (—)*3	● An improper signal is calculated by the ECM.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

- IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.
- RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.
- DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

- IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).
- RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).
- DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

—: Not applicable

Check Items (Possible Cause)	DTC Confirmation Procedure Quick Ref. ^{*1}	Overall Func- tion Check ^{*2}	MI Illumination	Reference Page
● ECM	IGN: ON	—	—	EC-CD-90
● Harness or connectors (The glow relay circuit is open or shorted.) ● Glow relay	IGN: ON	—	—	EC-CD-123
● ECM	IGN: ON	—	—	EC-CD-90
● Harness or connectors (The air conditioner relay circuit is open or shorted.) ● Air conditioner relay	IGN: ON	—	—	EC-CD-131
● Harness or connectors (The EGRC-solenoid valve A circuit is open or shorted.) ● EGRC-solenoid valve	RUNNING	—	Lighting up	EC-CD-134
● Harness or connectors (Brake switch circuits are open or shorted.) ● Brake lamp switch ● RDNT brake switch	RUNNING	—	Lighting up	EC-CD-141
● ECM	IGN: ON	—	—	EC-CD-90
● Harness or connectors (The ECCS-D relay circuit is shorted.) ● ECCS-D relay ● ECM	IGN: ON	—	Lighting up	EC-CD-90
● ECM	IGN: ON	—	Lighting up	EC-CD-90
● Harness or connectors (The injection timing control valve circuit is open or shorted.) ● Injection timing control valve	IGN: ON	—	Lighting up	EC-CD-85
● ECM ● Needle lift sensor ● Low battery voltage	RUNNING	—	Lighting up	EC-CD-101

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".
Details are described in each specific TROUBLE DIAGNOSIS FOR DTC.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.
In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".
When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.
● During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.
● This is Quick Reference of "OVERALL FUNCTION CHECK".
Details are described in each specific TROUBLE DIAGNOSIS FOR DTC.

*3: CONSULT-II may not detect, but self-diagnostic results are available with MI.

*4: Imaginary sensor, which produces secondary engine revolution signal using needle lift sensor pulse.

*5: The atmospheric pressure sensor is located inside the ECM and is not replaceable.

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

ENGINE RELATED ITEMS

Diagnostic trouble code No.	Detected items (Screen terms for CONSULT-II, "SELF-DIAG RESULTS" mode)	Malfunction is detected when ...
97	MI (—)*3	<ul style="list-style-type: none"> ● MI (malfunction indicator) circuit is open or shorted.
98	GLOW LAMP CIRCUIT (—)*3	<ul style="list-style-type: none"> ● Glow lamp circuit is open or shorted.

Abbreviations for Quick Reference of "DTC CONFIRMATION PROCEDURE"

- IGN: ON : Turning the ignition switch ON is required for checking the function of the sensor, switch, solenoid and circuit.
- RUNNING : Running engine is required for checking the function of the sensor, switch, solenoid and circuit.
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required.
- DRIVING : Driving the vehicle in the specified pattern is required.

Abbreviations for Quick Reference of "OVERALL FUNCTION CHECK"

- IGN: ON : Turning the ignition switch ON is required for the ECM to detect a malfunction (if one exists).
- RUNNING : Running engine is required for the ECM to detect a malfunction (if one exists).
- LIFTING : Lifting up the vehicle, running engine and spinning wheels are required for the ECM to detect a malfunction (if one exists).
- DRIVING : Driving the vehicle in the specified pattern is required for the ECM to detect a malfunction (if one exists).

**Diagnostic Trouble Code (DTC) Chart
(Cont'd)**

—: Not applicable

Check Items (Possible Cause)	DTC Confirmation Procedure Quick Ref. ^{*1}	Overall Func- tion Check ^{*2}	MI Illumination	Reference Page
<ul style="list-style-type: none"> ● Harness or connectors (The MI circuit is open or shorted.) ● MI lamp ● ECM 	IGN: ON	—	—	EC-CD-146
<ul style="list-style-type: none"> ● Harness or connectors (The glow indicator lamp circuit is open or shorted.) ● Glow lamp 	IGN: ON	—	—	EC-CD-123

*1: ● This is Quick Reference of "DTC CONFIRMATION PROCEDURE".
 Details are described in each specific TROUBLE DIAGNOSIS FOR DTC.

*2: ● The "OVERALL FUNCTION CHECK" is a simplified and effective way to inspect a component or circuit.
 In some cases, the "OVERALL FUNCTION CHECK" is used rather than a "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".
 When no DTC CONFIRMATION PROCEDURE is available, the "NG" result of the OVERALL FUNCTION CHECK can be considered to mean the same as a DTC detection.

- During an "NG" OVERALL FUNCTION CHECK, the DTC might not be confirmed.
- This is Quick Reference of "OVERALL FUNCTION CHECK".
 Details are described in each specific TROUBLE DIAGNOSIS FOR DTC.

*3: CONSULT-II may not detect, but self-diagnostic results are available with MI.

Symptom Matrix Chart

SYSTEM — Basic engine control system		SYMPTOM																		Reference page	Feature of symptom, Check point					
		HARD/NO START/RESTART (EXCP. HA)				ENGINE STALL				SYMPTOM																
New CT/CS		AA				AB				AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	AP	HA	Malfunction indicator illuminates.	Can be detected by CONSULT-II?	Fuel cut	Reference page	Feature of symptom, Check point
Injection timing	Advanced	○	○	●	●			○		●				○	○				●			○			EC-CD-41	
	Retarded	○	○	●	●			○		●				○	○					●		○			EC-CD-41	
Electric injection pump mainframe		●	●	●	●	○	○	○	○	○	○	○	○	○	○				○	○		○	○	○	—	*1
Injection nozzle		○	○	○	○	○	○	○		●	○	○	○	●	●				●						EC-CD-20	*2
Glow system		○	○	●	●					●										●					EC-CD-123	
Engine body		○	○	●	●	○	○	○		●	○	○	○	●	●		○	○	○	○		●			EM-section	*3
EGR system										●	●								●						EC-CD-134	
Air cleaner and ducts										●	●								●			○			MA-section	*4

● : High Possibility Item
 ○ : Low Possibility Item
 *1: Insufficient or excess amount. Governor malfunction may be the cause.
 *2: Depends on open-valve pressure and spray pattern.
 *3: Caused mainly by insufficient compression pressure.
 *4: Symptom varies depending on off-position of air duct, etc.

Symptom Matrix Chart (Cont'd)

Feature of symptom Check point		Reference page												Reference page														
SYMPTOM	Malfunction	New CT/CS												Engine control module														
		HA	AP	AM	AL	AK	AJ	AH	AG	AF	AE	AD	AC	AB	AA	EC-CD-65	EC-CD-69	EC-CD-73	EC-CD-76	EC-CD-80	EC-CD-85	EC-CD-101	EC-CD-104	EC-CD-108	EC-CD-112	EC-CD-119		
Fuel cut																												
Can be detected by CONSULT-II?																												
Malfunction indicator illuminates.																												
DEAD BATTERY (UNDER CHARGE)																												
ABNORMAL SMOKE COLOR	WHITE SMOKE																											
	BLACK SMOKE																											
EXCESSIVE OIL CONSUMPTION																												
EXCESSIVE FUEL CONSUMPTION																												
OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE																												
SLOW/NO RETURN TO IDLE																												
IDLING VIBRATION																												
ROUGH IDLE/HUNTING																												
LOW IDLE																												
HI IDLE																												
POOR ACCELERATION																												
LACK OF POWER																												
SPARK KNOCK/DETONATION																												
HESITATION/SURGING/FLAT SPOT																												
ENGINE STALL	WHEN DECELERATING																											
	DURING DRIVING																											
	AT IDLE																											
HARD/NO START/ RESTART (EXCP. HA)	HARD TO START WHEN ENGINE IS HOT																											
	HARD TO START WHEN ENGINE IS COLD																											
	NO START (without first firing)																											
	NO START (with first firing)																											
Mass air flow sensor circuit	open, ground short																											
Engine coolant temperature sensor circuit	open, short																											
Vehicle speed sensor circuit	open, short																											
Control sleeve position sensor circuit	open, short																											
Electric governor circuit	open, ground short																											
Injection timing control valve circuit	short																											
Needle lift sensor circuit	open, short																											
Fuel cut solenoid valve circuit	ground short																											
Fuel temperature sensor circuit	open, short																											
Accelerator position sensor circuit	open, short																											
Crankshaft position sensor (TDC) circuit	open, short																											
	noise																											

CONSULT-II Reference Value in Data Monitor Mode

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.


MONITOR ITEM	CONDITION	SPECIFICATION
CKPS•RPM (TDC)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.
CKPS•RPM-PUMP		
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 	More than 70°C (158°F)
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value 	Almost the same speed as the CONSULT-II value
FUEL TEMP SEN	<ul style="list-style-type: none"> ● Engine: After warming up 	More than 40°C (104 °F)
ACCEL POS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Accelerator pedal: release
		Accelerator pedal: depress
OFF ACCEL POS	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Accelerator pedal: release
		Accelerator pedal: slightly open
C/SLEEV POS/S	<ul style="list-style-type: none"> ● Engine: After warming up 	Approx. 2.5V
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	11 - 14V
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 	OFF → ON → OFF
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: "OFF"
		Air conditioner switch: "ON" (Compressor operates.)
IGN SW	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF 	ON → OFF
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load 	Idle
		2,000 rpm
ACT INJ TIMG	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load ● At sea level 	Idle
		2,000 rpm
TARGET F/INJ	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load ● At sea level 	Idle
		2,000 rpm
BRAKE SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: released
		Brake pedal: depressed
BRAKE SW 2	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: released
		Brake pedal: depressed
FUEL CUT S/V	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF 	ON → OFF
AIR COND RLY	<ul style="list-style-type: none"> ● Air conditioner switch: OFF → ON 	OFF → ON
GLOW RLY	<ul style="list-style-type: none"> ● Refer to EC-CD-129. 	
COOLING FAN	<ul style="list-style-type: none"> ● When cooling fan is stopped. ● When cooling fan operates at low speed. ● When cooling fan operates at high speed. 	OFF
		LOW
		HI
EGRC SOL/V A	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: "N" ● No-load ● At sea level 	Idle
		2,800 rpm

Major Sensor Reference Graph in Data Monitor Mode



The following are the major sensor reference graphs in “DATA MONITOR” mode.
(Select “HI SPEED” in “DATA MONITOR” with CONSULT-II.)

ACCEL POS SEN, C/SLEEV POS/S, ACT INJ TIMG

Below is the data for “ACCEL POS SEN”, “C/SLEEV POS/S” and “ACT INJ TIMG” when revving engine quickly up to 3,000 rpm under no load after warming up engine sufficiently.
Each value is for reference, the exact value may vary.



NEF780



ECM Terminals and Reference Value

PREPARATION


The ECM is located beneath the heater unit. To access the ECM, remove the center console under cover at the passenger side. Perform all voltage measurements with all connectors connected. Since the ECM harness connector cannot be accessed from the backside, voltages should be measured at the nearest connector to the sensors or actuators to be measured.

When measuring:

- Use extreme care not to touch 2 pins at the same time.
- Note that the data is for comparison and may not be exact.
- Use care not to enlarge the opening to keep the seal in good condition.

**ECM Terminals and Reference Value
(Cont'd)**

ECM HARNESS CONNECTOR TERMINAL LAYOUT



ECM INSPECTION TABLE



Specification data are reference values and are measured between each terminal and ④⑥ (Engine control module ground).

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
1 24 46	B	ESSC ground	Engine is running. └ Idle speed	Engine ground (Probe this terminal with ⊖ tester probe when measuring.)
2	L/OR	Tachometer	Engine is running. (Warm-up condition) └ Idle speed	Approximately 1.1 - 1.5V SEF550S
			Engine is running. └ Engine speed is 2,000 rpm	Approximately 1.1 - 1.5V SEF551S


**ECM Terminals and Reference Value
(Cont'd)**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
4 5 49	B/L	Electric governor ground	<p>Engine is running. (Warm-up condition)</p> <p>└ Idle speed</p>	<p>Approximately 10.5V</p>
			<p>Engine is running. (Warm-up condition)</p> <p>└ Engine speed is 2,000 rpm</p>	<p>Approximately 10.5</p>
7	W	Control sleeve position sensor power supply	<p>Engine is running.</p> <p>└ Idle speed</p>	<p>Approximately 2.6V</p>
8	W	Crankshaft position sensor (TDC) (Signal)	<p>Engine is running. (Warm-up condition)</p> <p>└ Idle speed</p>	<p>Approximately 0V</p>
			<p>Engine is running.</p> <p>└ Engine speed is 2,000 rpm</p>	<p>Approximately 0V</p>
11	B	Needle lift sensor ground	Ignition switch "ON"	Approximately 0V




**ECM Terminals and Reference Value
(Cont'd)**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
12	W	Needle lift sensor	Engine is running. (Warm-up condition) └ Idle speed	Approximately 3.8 - 4.0V 
			Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm	Approximately 3.8 - 4.0V 
13	L/W	Mass air flow sensor	Engine is running. (Warm-up condition) └ Idle speed	1.9 - 2.3V
			Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm	2.5 - 2.9V
14	L/OR	Engine coolant temperature sensor	Engine is running.	0.6 - 4.8V Output voltage varies with engine coolant temperature.
15	W	Accelerator position sensor	Ignition switch "ON" └ Accelerator pedal released	0.4 - 0.6V
			Ignition switch "ON" └ Accelerator pedal fully depressed	Approximately 4.0V
16	B/Y	Start signal	Ignition switch "ON"	Approximately 0V
			Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)
19	W	Mass air flow sensor power supply	Ignition switch "ON"	Approximately 5V
20 39	R/B	Brake switch 2	Ignition switch "ON" └ Brake pedal released	Battery voltage (11 -14V)
			Ignition switch "ON" └ Brake pedal depressed	0V
21	OR	Crankshaft position sensor (TDC) ground & mass air flow sensor ground	Engine is running. └ Idle speed	Approximately 0V


**ECM Terminals and Reference Value
(Cont'd)**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
23 45 68	R	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
25	P	EGRC-solenoid valve A	Engine is running. (Warm-up condition) └ Idle speed	BATTERY VOLTAGE (11 - 14V)
			Engine is running. (Warm-up condition) └ Engine speed is 2,800 rpm	Approximately 0.3V
26	OR/L	Malfunction indicator	Ignition switch "ON"	Approximately 1.0V
			Engine is running. └ Idle speed	BATTERY VOLTAGE (11 - 14V)
27	OR	Glow lamp	Ignition switch "ON" └ Glow lamp is "ON".	Approximately 1.0V
			Ignition switch "ON" └ Glow lamp is "OFF"	BATTERY VOLTAGE (11 - 14V)
28	L/W	Air conditioner relay	Engine is running. └ Both A/C switch and blower switch are "ON"	Approximately 0.4V
			Engine is running. └ A/C switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
29	R	Control sleeve position sensor (Reference signal)	Engine is running. (Warm-up condition) └ Idle speed	Approximately 2.6V 
30	G/B	Data link connector for CONSULT-II	Engine is running.	Approximately 0V
61	GY/L		└ Idle speed (CONSULT-II is connected and turned on)	Approximately 4 - 9V
64	G/R			Approximately 0V
33	B	Sensors' ground	Engine is running. └ Idle speed	Approximately 0V
38	BR	Ignition switch	Ignition switch "LOCK"	0V
			Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

**ECM Terminals and Reference Value
(Cont'd)**





TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
42	W/G	Engine control module relay (Self-shutoff)	Engine is running.	0 - 1V
			Ignition switch "LOCK" └ For a few seconds after turning ignition switch to the "LOCK" position	
			Ignition switch "LOCK" └ Following a few seconds delay after turning ignition switch to the "LOCK" position	BATTERY VOLTAGE (11 - 14V)
43	OR/W	Vehicle speed sensor	Engine is running.	0 - Approximately 4.2V  (V) SEF552S
			└ Lift up the vehicle. └ In 2nd gear position └ Vehicle speed is 40 km/h (25 mph)	
44	R/G	Stop lamp switch	Ignition switch "ON" └ Brake pedal released	0V
			Ignition switch "ON" └ Brake pedal depressed	Battery voltage (11 - 14V)
47	LG/R	Cooling fan relay (Low speed)	Engine is running. └ Cooling fan is not operating.	BATTERY VOLTAGE (11 - 14V)
			Engine is running. └ Cooling fan is operating.	Approximately 0.4V
50	W/R	Glow relay	Refer to "Glow control System".	
51	B/Y	Injection timing control valve	Engine is running. (Warm-up condition) └ Idle speed	Approximately 9V  (V) SEF564S
			Engine is running. (Warm-up condition) └ Engine speed is 2,000 rpm	Approximately 8V  (V) SEF565S

**ECM Terminals and Reference Value
(Cont'd)**

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
52	B	Control sleeve position sensor ground	Engine is running. └ Idle speed	Approximately 2.6V 
			Ignition switch "LOCK"	Approximately 0V
53	SB	Fuel cut solenoid valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "LOCK"	Approximately 0V
54	LG	Cooling fan relay (High speed)	Engine is running. └ Cooling fan is not operating. └ Cooling fan is operating at low speed.	BATTERY VOLTAGE (11 - 14V)
			Engine is running. └ Cooling fan is operating at high speed.	Approximately 0.5V
55	BR	Accelerator position sensor ground	Engine is running. └ Idle speed	Approximately 0V
57	LG/W	Accelerator position sensor power supply	Ignition switch "ON"	Approximately 5V
59	OR	Immobilizer communication	Ignition switch "ON"	BATTERY VOLTAGE (4 - 14V)
62	GY	Air conditioner switch	Engine is running. └ Both air conditioner switch and blower switch are "ON" (Compressor operates)	Approximately 0V
			Engine is running. └ Air conditioner switch is "OFF"	BATTERY VOLTAGE (11 - 14V)
63	R/Y	Fuel temperature sensor	Engine is running.	0.6 - 4.8V Output voltage varies with fuel temperature.
65	GY	Accelerator position switch (Idle)	Ignition switch "ON" └ Accelerator pedal released	Approximately 0V
			Ignition switch "ON" └ Accelerator pedal depressed	Approximately 2.7V







Main Power Supply and Ground Circuit

EC-MAIN-01








REFER TO THE FOLLOWING
 (M1) FUSE BLOCK - Junction Box (J/B)

Main Power Supply and Ground Circuit (Cont'd)



Main Power Supply and Ground Circuit (Cont'd)



D

CHECK VOLTAGE BETWEEN ENGINE CONTROL MODULE RELAY AND GROUND.
Check voltage between engine control module relay connector terminals ②, ③ and ground with CONSULT-II or tester.
Voltage: Battery voltage

NG → Check the following:
● 15A fuse
● Harness for open or short-circuit between engine control module relay and battery.
If NG, replace fuse or repair harness or connectors.

OK

E

CHECK OUTPUT SIGNAL CIRCUIT.
Check harness continuity between ECM connector terminal ④② and engine control module relay connector terminal ①.
Continuity should exist.
If OK, check harness for short-circuit.

NG → ● Check harness connectors (E43), (F2)
Repair harness or connectors.

OK

F

CHECK ENGINE CONTROL MODULE RELAY.
1. Apply 12V direct current between engine control module relay connector terminals ① and ②.
2. Check continuity between engine control module relay connector terminals ③ and ⑤.
12V (① - ②) applied: Continuity exists.
No voltage applied: No continuity

NG → Replace engine control module relay.

OK

G


CHECK GROUND CIRCUIT.
1. Turn ignition switch to "LOCK" position.
2. Check harness continuity between ECM connector terminals ①, ②④, ④⑥ and engine ground.
Continuity should exist.
If resistance is too high, loosen, clean and retighten engine ground.
If OK, check harness for short-circuit.

NG → Repair harness or connectors.

OK

Check ECM pin terminals for damage and check the connection of ECM harness connector.

INSPECTION END



Mass Air Flow Sensor (MAFS)

The mass air flow sensor measures the amount of intake air by analysing a part of the entire flow. When intake air flows into the intake manifold, heat is withdrawn from the hot film. By regulating the electrical current that flows through the hot film, the ECM maintains the hot film temperature on a constant level. The amount of electric current that is needed to keep the hot film on a constant temperature level is proportional to the mass of air that flows into the engine.



Diagnostic Trouble Code No.	Malfunction is detected when . . .	Check Items (Possible Cause)
12	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is entered to ECM. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE






- 1) Turn ignition switch to "ON" position.
 - 2) Select "DATA MONITOR" mode with CONSULT-II.
 - 3) Start engine and wait for at least 20 seconds.
- OR
- 1) Start engine and wait for at least 20 seconds.
 - 2) Turn ignition switch to "LOCK" position, wait for at least 5 seconds and then turn to "ON" position.
 - 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Mass Air Flow Sensor (MAFS) (Cont'd)

EC-MAFS-01




Mass Air Flow Sensor (MAFS) (Cont'd)
DIAGNOSTIC PROCEDURE




**Mass Air Flow Sensor (MAFS) (Cont'd)
COMPONENT INSPECTION**

Mass air flow sensor



1. Turn ignition switch to "ON" position.
2. Start engine and warm it up sufficiently.
3. Check voltage between mass air flow sensor connector terminal ⑤ and ground.



Conditions	Voltage V
Ignition switch "ON" position (Engine stopped.)	Approximately 1.0
Idle (Engine is warmed-up sufficiently.)	1.9 - 2.3



4. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.



Engine Coolant Temperature (ECT) Sensor

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

(Reference data)

Engine coolant temperature °C (°F)	Voltage (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.3	0.68 - 1.00
90 (194)	1.0	0.236 - 0.260



Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
13	<ul style="list-style-type: none"> An excessively high or low voltage from the sensor is entered to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Engine coolant temperature sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch to "ON" position.
 - 2) Select "DATA MONITOR" mode with CONSULT-II.
 - 3) Wait at least 5 seconds.
- OR
- 1) Turn ignition switch to "ON" position and wait at least 5 seconds.
 - 2) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
 - 3) Perform diagnostic test mode II (Self-diagnostic results).





**Engine Coolant Temperature (ECT) Sensor
(Cont'd)**

EC-ECTS-01



Engine Coolant Temperature (ECT) Sensor (Cont'd)

DIAGNOSTIC PROCEDURE




**Engine Coolant Temperature (ECT) Sensor
(Cont'd)**


COMPONENT INSPECTION

Engine coolant temperature sensor


Check resistance as shown in the figure.



Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.0
90 (194)	0.236 - 0.260




If NG, replace engine coolant temperature sensor.



Vehicle Speed Sensor (VSS)

The vehicle speed sensor is installed in the transaxle. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
14	<ul style="list-style-type: none"> The almost 0 km/h (0 mph) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven. 	<ul style="list-style-type: none"> Harness or connector (The vehicle speed sensor circuit is open or shorted.) Vehicle speed sensor



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the vehicle speed sensor circuit. During this check, a DTC might not be confirmed.



- 1) Jack up drive wheels.
- 2) Start engine.
- 3) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT-II.


The vehicle speed on CONSULT-II should be able to exceed 10 km/h (6 mph) when rotating wheels with suitable gear position.

OR








- 1) Jack up drive wheels.
- 2) Start engine.
- 3) Rotate drive wheel by hand.
- 4) Check voltage between ECM connector terminal ④ and ground with voltage tester.

Voltage should vary between approx. 0 - 0.6V.



Vehicle Speed Sensor (VSS) (Cont'd)


EC-VSS-01



REFER TO THE FOLLOWING

(M1) FUSE BLOCK - Junction Box (J/B)

Vehicle Speed Sensor (VSS) (Cont'd)
DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK INPUT SIGNAL CIRCUIT.
1. Turn ignition switch to "LOCK" position.
2. Disconnect ECM harness connector and combination meter harness connector.
3. Check harness continuity between ECM connector terminal ④③ and combination meter connector terminal ⑨.
Continuity should exist.
If OK, check harness for short-circuit.

NG → Check the following:
● Harness connectors (M50, F104)
● Harness for open or short-circuit between ECM and combination meter.
If NG, repair harness or connectors.


OK →
CHECK SPEEDOMETER FUNCTION.
Make sure that speedometer functions correctly.

NG → Check the following:
● Harness connectors (M50, F104)
● Harness for open or short-circuit between combination meter and vehicle speed sensor.
If NG, repair harness or connectors.
Check vehicle speed sensor and its circuit. Refer to EL section.

OK →
Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.


INSPECTION END



Control Sleeve Position Sensor (CSPS)

The control sleeve position sensor is installed on the electric governor. It senses the position of control sleeve (rotor angle) while the control sleeve is being driven by the electric governor, and feeds it back to the ECM.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
15	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by ECM. ● An incorrect voltage signal from the sensor is detected by ECM during engine running. 	<ul style="list-style-type: none"> ● Harness or connectors (The control sleeve position sensor circuit is open or shorted.) ● Control sleeve position sensor




DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- ① 1) Turn ignition switch to "ON" position and select "DATA MONITOR" mode with CONSULT-II.
 - 2) Start engine and run it for at least 2 seconds at idle speed.
- OR
- ⓧ 1) Start engine and run it for at least 2 seconds at idle speed.
 - 2) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
 - 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)".

**Control Sleeve Position Sensor (CSPS)
(Cont'd)**





EC-CSPS-01



: Detectable line for DTC
 : Non-detectable line for DTC



Control Sleeve Position Sensor (CSPS) (Cont'd) DIAGNOSTIC PROCEDURE



Control Sleeve Position Sensor (CSPS)

(Cont'd)


COMPONENT INSPECTION


Control sleeve position sensor

1. Disconnect electronic injection pump harness connector.
2. Check continuity between terminals ① and ③, ② and ③.

Resistance: Approximately 6.0Ω [at 25°C (77°F)]

If NG, take proper action.






Electric Governor

The electric governor is built into the fuel injection pump. It moves the control sleeve to increase or decrease the amount of fuel injected.

When current flows through the coil, a magnetic force is produced, rotating the rotor. The rotor shaft is installed to the control sleeve via a ball pin which is eccentrically situated in relation to the rotor shaft. With this arrangement, the control sleeve can be moved in relation to rotor rotation.

The rotor's rotating angle is determined by a balanced condition of magnetic force (generated by current flow regulated by means of the ECM) and tension of return spring (installed to rotor). The larger the current flow through the coil, the greater the rotor's rotating angle. This means that the control sleeve moves to the right, increasing the amount of fuel injected.

The ECM regulates the current flow through the coil by changing the duty cycle ratio which controls the ON-OFF operation of the electric governor grounding circuit.



Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
18	<ul style="list-style-type: none"> ● Fuel injection feedback system does not operate properly. [This system consists essentially of ECM, electric governor and control sleeve position sensor.] 	<ul style="list-style-type: none"> ● Main power supply circuit (ECM connector terminals ②③, ④⑤, ⑥⑧) and fuse ● Harness or connectors (Electric governor and control sleeve position sensor circuit) ● Electric governor ● ECM

Electric Governor (Cont'd)**DIAGNOSTIC TROUBLE CODE CONFIRMATION
PROCEDURE**

- 1) Turn ignition switch to "ON" position and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine above 1,200 rpm.
- 3) Run it for 2 seconds above 1,200 rpm. Return engine speed to idle.

OR









- 1) Start engine above 1,200 rpm.
- 2) Run engine for 2 seconds above 1,200 rpm. Return engine speed to idle.
- 3) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Note: If malfunction occurs intermittently, conduct suitable driving pattern for 10 minutes. This makes it possible to determine DTC.





Electric Governor (Cont'd)

EC-GOVNR-01

: Detectable line for DTC
 : Non-detectable line for DTC



**Electric Governor (Cont'd)
DIAGNOSTIC PROCEDURE**





**Electric Governor (Cont'd)
COMPONENT INSPECTION****Electric governor**

1. Disconnect electronic injection pump harness connector.
2. Check continuity between injection pump connector terminals ④ and ⑦.

Resistance: Approximately 1.0Ω [at 25°C (77°F)]

If NG, replace.





Injection Timing Control Valve

The injection timing control valve is built into the fuel injection pump. It controls the timer piston to change the fuel injection timing.

The timing control valve is a solenoid valve located in the line between high-pressure chamber and low-pressure chamber. It changes fuel pressure in the high-pressure chamber.

When current flows through the solenoid (the solenoid turns ON), the timing control valve opens, advancing fuel injection timing. When current does not flow through it, the timing control valve closes, retarding injection timing.

The ECM emits an ON-OFF duty cycle signal. The longer the OFF-duration, the greater the advance angle. The longer the ON-duration, the greater the retard angle. This means that changing the ON-OFF duty cycle ratio makes it possible to achieve an optimal advance angle and accurately control fuel injection timing.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible cause)
21	<ul style="list-style-type: none"> Injection timing feedback system does not operate properly. (This system consists essentially of ECM, injection timing control valve and needle lift sensor.) 	<ul style="list-style-type: none"> Harness or connectors [Injection timing control valve, needle lift sensor, crankshaft position sensor (TDC) circuits] Injection timing control valve Needle lift sensor Crankshaft position sensor (TDC) Air in fuel line
94	<ul style="list-style-type: none"> Injection timing control valve circuit it open or shorted. 	<ul style="list-style-type: none"> Harness or connectors (The Injection timing control valve is open or shorted.) Injection timing control valve

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: If both DTC 21 and 34 or 47 are displayed, perform TROUBLE DIAGNOSIS FOR DTC 34 or 47. (See EC-CD-101 or EC-CD-119.)

- 1) Turn ignition switch to "ON" position and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine. Run engine for 10 seconds at idle.

OR

- 1) Start engine. Run engine for 10 seconds at idle.
- 2) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Note: If malfunction occurs intermittently, conduct suitable driving pattern for 10 minutes. This makes it possible to determine DTC.

Injection Timing Control Valve (Cont'd)
DIAGNOSTIC TROUBLE CODE 94 CONFIRMATION
PROCEDURE

- 1) Turn ignition switch to "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 2 seconds.



OR







- 1) Turn ignition switch to "ON" position.
- 2) Wait at least 2 seconds.
- 3) Turn ignition switch to "LOCK" position, wait at least 5 seconds and turn to "ON" position.
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Injection Timing Control Valve (Cont'd)

EC-TCV-01



**Injection Timing Control Valve (Cont'd)
DIAGNOSTIC PROCEDURE**



INSPECTION START

A
CHECK FOR AIR IN FUEL FILTER.
1. Move priming pump up and down to purge air from fuel filter.
2. Perform "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

B
CHECK POWER SUPPLY.
1. Turn ignition switch to "LOCK" position.
2. Disconnect injection timing control valve harness connector.
3. Turn ignition switch to "ON" position.
4. Check voltage between injection timing control valve connector terminal ③ and ground with CONSULT-II or tester.
Voltage: Battery voltage

NG

Check the following:

- Harness connectors (E89, F96)
- Electronic injection pump harness connector (F49)
- 15A fuse
- Harness for open or short-circuit between injection timing control valve harness connector and engine control module relay.

If NG, repair harness or connectors.

C
CHECK OUTPUT SIGNAL CIRCUIT.
1. Turn ignition switch to "LOCK" position.
2. Disconnect ECM harness connector.
3. Check harness continuity between injection timing control valve connector terminal ② and ECM terminals ⑤1.
Continuity should exist.
If OK, check harness for short-circuit.

NG

Check the following:

- Electronic injection pump harness connector (F49)
- Harness for open or short-circuit between injection timing control valve and ECM.



If NG, repair harness or connectors.

OK

↓

Ⓐ


Injection Timing Control Valve (Cont'd)



COMPONENT INSPECTION

Injection timing control valve

1. Disconnect injection timing control valve harness connector.
2. Check resistance between terminals ② and ③.
Resistance: Approximately 15Ω [at 25°C (77°F)]
 If NG, replace injection timing control valve.



Engine Control Module (ECM)

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The module monitors and controls the engine operation.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
31	<ul style="list-style-type: none"> ● ECM calculation function is malfunctioning. 	<ul style="list-style-type: none"> ● ECM *
82	<ul style="list-style-type: none"> ● An excessively high or low voltage from the atmospheric pressure sensor is detected by the ECM. 	<ul style="list-style-type: none"> ● ECM *
84	<ul style="list-style-type: none"> ● ECM reference voltage (2.5V) is excessively high or low. 	<ul style="list-style-type: none"> ● ECM *
91	<ul style="list-style-type: none"> ● ECM version number or switching function is not plausible. 	<ul style="list-style-type: none"> ● ECM *
93	<ul style="list-style-type: none"> ● Ignition switch "ON" signal evaluation circuit in ECM is malfunctioning. 	<ul style="list-style-type: none"> ● ECM *

* Actually inspecting the ECM inside circuit is impossible. Then, ECM may be replaced.

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch to "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 2 seconds.


OR



- 1) Turn ignition switch to "ON" position.
- 2) Wait at least 2 seconds.
- 3) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results).


Cooling Fan (Overheat)

SYSTEM DESCRIPTION



The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, air conditioner system pressure and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF]. This system indirectly relates to diagnostic trouble code 28 (Overheat).

Operation



ON-BOARD DIAGNOSIS LOGIC

This diagnosis continuously monitors the engine coolant temperature.

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
28	<ul style="list-style-type: none"> An excessive high engine coolant temperature sensor signal is detected by the ECM. (Overheat) 	<ul style="list-style-type: none"> Harness or connectors (The cooling fan circuit is open or shorted.) Cooling fan Radiator hose Radiator Radiator cap Water pump Thermostat Fan belt Engine coolant temperature sensor <p>For more information, refer to "12 MAIN CAUSES OF OVERHEATING", EC-CD-99.</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- a. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED FLUIDS AND LUBRICANTS").
- b. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Cooling Fan (Overheat) (Cont'd)


OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.

WARNING:



Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.



ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C

SEF111X



- 1) Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level. If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to "DIAGNOSTIC PROCEDURE", EC-CD-94.
- 2) Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to "DIAGNOSTIC PROCEDURE", EC-CD-94.
- 3) Turn ignition switch to "ON" position.
- 4) Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II (LOW speed and HI speed).

OR


- 3) Start engine.
Be careful not to overheat engine.
- 4) Set temperature control switch to full cold position.
- 5) Push Air Conditioner switch to "ON" position.
- 6) Turn blower fan switch to "ON" position.
- 7) Run engine at idle for a few minutes with Air Conditioner operating.
Be careful not to overheat engine.
- 8) Make sure that both cooling fans operate at low speed.
- 9) Turn ignition switch to "LOCK" position.
- 10) Push Air Conditioner switch and blower fan switch to "OFF" position.
- 11) Disconnect engine coolant temperature sensor harness connector.
- 12) Connect 150Ω resistor to engine coolant temperature sensor harness connector.
- 13) Restart engine and make sure that both cooling fans operate at higher speed than low speed.
Be careful not to overheat engine.

TROUBLE DIAGNOSIS FOR DTC 28


CD20T

Cooling Fan (Overheat) (Cont'd)


EC-COOL/F-01



— : Detectable line for DTC
 - - - : Non-detectable line for DTC




REFER TO THE FOLLOWING
 E127 FUSE BLOCK - Junction Box (J/B)



YEC312


**Cooling Fan (Overheat) (Cont'd)
DIAGNOSTIC PROCEDURE**



A

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C


SEF111X



B

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLAN TEMP/S	XXX °C

SEF111X



INSPECTION START

A

CHECK COOLING FAN LOW SPEED OPERATION.

1. Disconnect cooling fan relay-3.
2. Turn ignition switch to "ON" position.
3. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.

OR

2. Start engine.
3. Set temperature switch at full cold position.
4. Turn Air Conditioner switch to "ON" position.
5. Turn blower fan switch to "ON" position.
6. Run engine at idle speed for a few minutes with Air Conditioner operating.
7. Make sure that both cooling fans operate at low speed.

NG → Check cooling fan low speed control circuit. (Go to PROCEDURE A .)

OK

B

CHECK COOLING FAN HIGH SPEED OPERATION.

1. Turn ignition switch to "LOCK" position.
2. Reconnect cooling fan relay-3.
3. Disconnect cooling fan relay-1.
4. Turn ignition switch to "ON" position.
5. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.

OR






4. Turn Air Conditioner switch and blower fan switch to "OFF" position.
5. Disconnect engine coolant temperature sensor harness connector.
6. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
7. Restart engine and make sure that both cooling fans operate at higher speed than low speed.

NG → Check cooling fan high speed control circuit. (Go to PROCEDURE B .)

OK

ⓑ
(Go to EC-CD-98.)

Cooling Fan (Overheat) (Cont'd)



PROCEDURE A

INSPECTION START

C CHECK POWER SUPPLY.

1. Turn ignition switch to "LOCK" position.
2. Disconnect cooling fan relay-1 and fan motor-1 connector.
3. Turn ignition switch to "ON" position.
4. Check voltage between cooling fan motor-1 connector terminal ①, fan relay-1 connector terminal ① and ground.

Voltage: Battery voltage

NG

Check the following:

- 10A fuse
- 40A, 100A, fusible links
- Harness for open or short-circuit between cooling fan motor-1 and battery.
- Harness for open or short-circuit between cooling fan relay-1 and fuse.

If NG, replace fuse or fusible links or repair harness or connectors.

CHECK GROUND CIRCUIT.

1. Turn ignition switch to "LOCK" position.
2. Disconnect cooling fan relay-2 and fan motor-2 harness connector.
- D** 3. Check harness continuity between cooling fan relay-1 connector terminal ⑤ and cooling fan relay-2 connector terminal ④; cooling fan motor-1 connector terminal ② and cooling fan relay-2 connector terminal ③. **Continuity should exist.**
- E** 4. Check harness continuity between cooling fan motor-2 connector terminal ① and cooling fan relay-1 connector terminal ③; cooling fan motor-2 connector terminal ② and ground. **Continuity should exist.**

If OK, check harness for short-circuit.





NG

Repair harness or connectors.




OK

ⓐ

Cooling Fan (Overheat) (Cont'd)



Cooling Fan (Overheat) (Cont'd)



D

CHECK GROUND CIRCUIT.

- Turn ignition switch to "LOCK" position.
- Disconnect cooling fan motor-2 harness connector.

H 3. Check harness continuity between cooling fan motor-1 connector terminal ② and cooling fan relay-2 connector terminal ③; cooling fan motor-2 connector terminal ① and cooling fan relay-3 connector terminal ⑤; cooling fan relay-2 connector terminal ⑤ and ground.
Continuity should exist.
If OK, check harness for short-circuit.

I 4. Check harness continuity between cooling fan motor-2 terminal ② and ground.

NG → Repair harness or connectors.

OK

J

CHECK OUTPUT SIGNAL CIRCUIT.

- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal ⑤④ and cooling fan relay-3 connector terminal ② & cooling fan relay-2 connector terminal ②.
Continuity should exist.
If OK, check harness for short-circuit.

NG → Check the following:
● Harness connectors (E43), (F2)
● Harness for open or short-circuit between cooling fan relay-2, 3 and ECM.
If NG, repair harness or connectors.

OK

CHECK COMPONENT
(Cooling fan relay-2, 3).
Refer to "COMPONENT INSPECTION", EC-CD-100.

NG → Replace cooling fan relays.

OK

CHECK COMPONENTS
(Cooling fan motors).
Refer to "COMPONENT INSPECTION", EC-CD-100.

NG → Replace cooling fan motors.

OK





Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

Cooling Fan (Overheat) (Cont'd)



Perform FINAL CHECK by the following procedure after repair is completed.

1. Warm up engine. Run the vehicle for at least 20 minutes. Pay attention to engine coolant temperature gauge on the instrument panel. If the reading shows an abnormally high temperature, another part may be malfunctioning.
2. Stop vehicle and let engine idle. Check the intake and exhaust systems for leaks by listening for noise or visually inspecting the components.
3. Allow engine to cool and visually check for oil and coolant leaks. Then, perform "OVERALL FUNCTION CHECK".

Cooling Fan (Overheat) (Cont'd)

12 MAIN CAUSES OF OVERHEATING

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	-
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRICANTS" in MA section.
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
	4	● Radiator cap	● Pressure tester	78 - 98 kPa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm ² , 11 - 14 psi) 59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See "System Check" "ENGINE COOLING SYSTEM" in LC section.
ON*2	5	● Coolant leaks	● Visual	No leaks	See "System Check" "ENGINE COOLING SYSTEM" in LC section.
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section.
ON*1	7	● Cooling fan	● CONSULT	Operating	See "TROUBLE DIAGNOSIS FOR DTC 28".
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	-
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	-
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section.
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See "ENGINE MAINTENANCE" in MA section.
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYLINDER HEAD" in EM section.
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See "Inspection", "CYLINDER BLOCK" in EM section.

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 mph) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.

**Cooling Fan (Overheat) (Cont'd)
COMPONENT INSPECTION**

Cooling fan relays-1, -2, -3

Check continuity between terminals ③ and ⑤.



Conditions	Continuity
12V direct current supply between relay terminals ① and ②	Yes
No current supply	No

If NG, replace cooling fan relay.

Cooling fan relay-2

Check continuity between terminals ③ and ④.

Conditions	Continuity
No current supply	Yes
12V direct current supply between relay terminals ① and ②	No




Cooling fan motors-1 and -2

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Terminals	
	(⊕)	(⊖)
Cooling fan motor-1 and -2	①	②

Cooling fan motor should operate.

If NG, replace cooling fan motor.



Needle Lift Sensor (NLS)

The needle lift sensor is built into the No. 1 nozzle. Its inductive pick-up element senses the lifting of the injection nozzle needle and thus the start of injection. The signal is evaluated by the ECM and compared with the target timing. Deviations in timing, for example caused by changes in fuel temperature, are sensed by the ECM and corrected.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
34	<ul style="list-style-type: none"> ● An improper signal from the sensor is sent to ECM. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Needle lift sensor ● Air in fuel line ● Clogging No. 1 injection nozzle

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: Before DTC confirmation, be sure to check battery voltage is above 9V.



- 1) Turn ignition switch to "ON" position and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for 2 seconds above 1,200 rpm.


OR





- 1) Start engine and run it for 215 seconds above 1,200 rpm.
- 2) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Needle Lift Sensor (NLS) (Cont'd)





EC-NLS-01



— : Detectable line for DTC
 - - - : Non-detectable line for DTC



**Needle Lift Sensor (NLS) (Cont'd)
DIAGNOSTIC PROCEDURE**



INSPECTION START

A
CHECK FOR AIR IN FUEL FILTER.
1. Move priming pump up and down to purge air from fuel filter.
2. Perform "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE".

B
CHECK INPUT SIGNAL CIRCUIT.
1. Turn ignition switch to "LOCK" position.
2. Disconnect ECM harness connector and needle lift sensor harness connector.
3. Check harness continuity between needle lift sensor connector terminal ① and ECM connector terminal ⑫.
Continuity should exist.
If OK, check harness for short-circuit.

NG → Repair harness or connectors.

D
CHECK GROUND CIRCUIT.
Check resistance between needle lift sensor connector terminal ② and ECM connector terminal ⑪.
Continuity should exist.
If OK, check harness for short-circuit.


NG → Repair harness or connectors.

B
CHECK NO. 1 INJECTION NOZZLE FOR CLOGGING.
Refer to spray pattern test of "INJECTION NOZZLE".
If NG, replace No. 1 injection nozzle.

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END



Fuel Cut Solenoid Valve

When the ignition switch is OFF, the ECM turns the fuel cut solenoid valve OFF (under this condition, no current flows through the fuel cut solenoid valve), shutting off fuel supply. When the engine is not operating due to trouble, the fuel cut solenoid valve may be OFF even when the ignition switch is ON.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
36	<ul style="list-style-type: none"> ● Fuel cut solenoid valve circuit is malfunctioning. 	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● Fuel cut solenoid valve

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: If DTC 13 or 47 is displayed at the same time, perform TROUBLE DIAGNOSIS FOR DTC13 OR 47 first.



- 1) Turn ignition switch to "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine. (If no start, circuit is open).
- 4) Warm engine up sufficiently.
- 5) Turn ignition switch to "LOCK" position and wait at least 5 seconds.
- 6) Start engine and rev it up above 1,300 rpm. Release pedal and wait at least 3 seconds.



OR




- 1) Start engine. (If no start, circuit is open).
- 2) Warm engine up sufficiently.
- 3) Turn ignition switch to "LOCK" position and wait at least 5 seconds.
- 4) Start engine and rev it up above 1,300 rpm. Release pedal and wait at least 3 seconds.
- 5) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 6) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Fuel Cut Solenoid Valve (Cont'd)

EC-FCUT-01




Fuel Cut Solenoid Valve (Cont'd)
DIAGNOSTIC PROCEDURE



A

ACTIVE TEST	
FUEL CUT SOL/V	ON
MONITOR	
CKPS-RPM(TDC)	0rpm

C2FCS01



INSPECTION START

CHECK MAIN POWER SUPPLY.
Check power supply. Refer to EC-CD-62.

A

CHECK OUTPUT SIGNAL CIRCUIT.

1. Turn ignition switch to "ON" position.
2. Select "FUEL CUT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "ON" and "OFF" alternately.
4. Check that operating sound is emitted.

NG → Repair harness or connectors.

OR

1. Turn ignition switch to "LOCK" position.
2. Disconnect ECM harness connector and electronic injection pump harness connector.
3. Check harness continuity between fuel cut solenoid valve connector terminal ① and ECM connector terminal ⑤3.

Continuity should exist.
If OK, check harness for short.

OK

CHECK COMPONENT (Fuel cut solenoid valve).
Refer to "COMPONENT INSPECTION" on next page.

NG → Replace fuel cut solenoid valve.

OK

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.


Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

Fuel Cut Solenoid Valve (Cont'd)**COMPONENT INSPECTION****Fuel cut solenoid valve**

1. Remove fuel cut solenoid valve.
2. Check for lifting shaft when applying 12V direct current to terminals.

If NG, replace fuel cut solenoid valve.



Fuel Temperature Sensor (FTS)

The fuel temperature sensor is used to detect the fuel temperature in the injection pump. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

The sensor is built into the inside electrical circuit of the injection pump.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
42	<ul style="list-style-type: none"> ● An excessively high or low voltage from the sensor is detected by ECM. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel temperature sensor

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch to "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.




OR






- 1) Turn ignition switch to "ON" position and wait at least 5 seconds.
- 2) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Fuel Temperature Sensor (FTS) (Cont'd)

EC-FTS-01



Fuel Temperature Sensor (FTS) (Cont'd)
DIAGNOSTIC PROCEDURE



INSPECTION START

A
CHECK POWER SUPPLY.
1. Turn ignition switch to "LOCK" position.
2. Disconnect fuel temperature sensor harness connector.
3. Turn ignition switch to "ON" position.
4. Check voltage between injection pump connector terminal ⑥ and ground with CONSULT-II or voltage tester.
Voltage:
Approximately 5V

NG → Repair harness or connectors.

B
CHECK GROUND CIRCUIT.
1. Turn ignition switch to "LOCK" position.
2. Check harness continuity between injection pump connector terminal ⑤ and ECM connector terminal ③③.
Continuity should exist.
If OK, check harness for short-circuit.

NG → Repair harness or connectors.

CHECK COMPONENT
(Fuel temperature sensor). Refer to "COMPONENT INSPECTION" on next page.

NG → Have the injection pump assembly serviced by an authorised service representative.

Disconnect and reconnect harness connectors in the circuits. Then retest.

Trouble is not fixed.


Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

**Fuel Temperature Sensor (FTS) (Cont'd)
COMPONENT INSPECTION**

Fuel temperature sensor

Wait until fuel temperature sensor reaches room temperature.
Check resistance between terminals ⑤ and ⑥.




Fuel temperature °C (°F)	Resistance kΩ
25 (77)	Approximately 1.9

If NG, have the injection pump assembly serviced by an authorised service representative.

Accelerator Position Sensor & Switch

The accelerator position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.



NEF822

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
43	<ul style="list-style-type: none"> An excessively low or high voltage from the sensor is detected by the ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor or switch circuit is open or shorted.) Accelerator position sensor Accelerator position switch

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

- 1) Turn ignition switch to "ON" position.
 - 2) Select "DATA MONITOR" mode with CONSULT-II.
 - 3) Depress accelerator pedal fully and keep it for at least 1 second. Then release it and wait at least 5 seconds.
- OR
- 1) Turn ignition switch to "ON" position.
 - 2) Depress accelerator pedal fully and keep it for at least 1 second. Then release it and wait at least 5 seconds.
 - 3) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
 - 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

**Accelerator Position Sensor & Switch
(Cont'd)****DIAGNOSTIC TROUBLE CODE CONFIRMATION
PROCEDURE (For accelerator stiching)**

- 1) Turn ignition switch to "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Start engine and rev it up above 1,300 rpm.
- 4) Depress brake pedal immediately after releasing accelerator pedal and keep it at least 5 seconds.




OR



- 1) Start engine and rev it up above 1,300 rpm.
- 2) Depress brake pedal immediately after releasing accelerator pedal and keep it at least 5 seconds.
- 3) Turn ignition switch to the "LOCK" position, wait at least 5 seconds and then turn to the "ON" position.
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.


Accelerator Position Sensor & Switch
(Cont'd)

EC-APS-01




**Accelerator Position Sensor & Switch
(Cont'd)**

EC-APP/SW-01








: Detectable line for DTC
 : Non-detectable line for DTC







Accelerator Position Sensor & Switch (Cont'd)

DIAGNOSTIC PROCEDURE



Accelerator Position Sensor & Switch (Cont'd)

DIAGNOSTIC PROCEDURE



INSPECTION START
(Accelerator position switch)

A

CHECK OVERALL FUNCTION.

1. Turn ignition switch to "ON" position.
2. Check "OFF ACCEL POS" in "DATA MONITOR" mode with CONSULT-II.

Accelerator pedal released: ON
Accelerator pedal depressed: OFF

OR

1. Turn ignition switch to "LOCK" position.
2. Check continuity between ECM connector terminal 65 and ground.

Continuity: Accelerator pedal released: No
Accelerator pedal depressed: Yes

OK → INSPECTION END

B

CHECK GROUND CIRCUIT.

1. Disconnect accelerator switch harness connector.
2. Check harness continuity between accelerator switch connector terminal 1 and engine ground.

Continuity should exist.

NG → Check the following:
● Harness connectors (M52, F103)
● Harness for open circuit between accelerator switch and engine ground.
If NG, repair harness or connectors.

C

CHECK INPUT SIGNAL CIRCUIT.
Check harness continuity between ECM connector terminal 65 and accelerator switch connector terminal 3.

Continuity should exist.

NG → Check the following:
● Harness connectors (F103, M52)
● Harness for open or short-circuit between accelerator switch and ECM

CHECK COMPONENT (Accelerator switch).
Refer to "COMPONENT INSPECTION" on next page.

NG → Replace accelerator switch.

OK → Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed → Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.


INSPECTION END

**Accelerator Position Sensor & Switch
(Cont'd)**

COMPONENT INSPECTION

Accelerator position sensor

1. Disconnect accelerator position sensor harness connector.
2. Make sure that resistance between accelerator position sensor terminals ② and ④ changes when opening throttle valve manually.



Throttle valve conditions	Resistance [at 25°C (77°F)]
Completely closed	Approximately 1.2 kΩ
Partially open	1.2 - 1.9 kΩ
Completely open	Approximately 1.9 kΩ

If NG, replace accelerator pedal assembly.


CAUTION:

- Do not disassemble accelerator pedal assembly.

COMPONENT INSPECTION

Accelerator switch

1. Disconnect accelerator switch harness connector.
2. Check continuity between accelerator switch connector terminals ① and ③.




Conditions	Continuity
Accelerator pedal released	No
Accelerator pedal depressed	Yes

If NG, replace accelerator pedal assembly.


CAUTION:

- Do not disassemble accelerator pedal assembly.



Crankshaft Position Sensor (TDC)

The crankshaft position sensor (TDC) monitors engine speed by means of signals from the sensing plate (with two protrusions) installed to the crankshaft pulley. The datum signal output is detected at ATDC 70° and sent to the ECM. The sensor signal is used for fuel injection control and fuel injection timing control.



Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
47	<ul style="list-style-type: none"> An incorrect signal from the sensor is detected by ECM during engine running and cranking. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open.) Crankshaft position sensor (TDC)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Before performing the following procedure, confirm that battery voltage is more than 9V.

If DTC 34 is displayed at the same time, perform trouble diagnosis for DTC34 first.



- ① 1) Turn ignition switch to “ON” position and select “DATA MONITOR” mode with CONSULT-II.
- 2) Start engine and run it for at least 3 seconds above 1,200 rpm.

OR





- ⓧ 1) Start engine and run it for at least 3 seconds above 1,200 rpm.
- 2) Turn ignition switch to “LOCK” position, wait at least 5 seconds and then turn to “ON” position.
- 3) Perform “Diagnostic Test Mode II” (Self-diagnostic results).

Crankshaft Position Sensor (TDC) (Cont'd)

EC-CKPS-01



**Crankshaft Position Sensor (TDC) (Cont'd)
DIAGNOSTIC PROCEDURE**





**Crankshaft Position Sensor (TDC) (Cont'd)
COMPONENT INSPECTION**


Crankshaft position sensor (TDC)

1. Disconnect crankshaft position sensor (TDC) harness connector.
2. Loosen the fixing bolt of the sensor.
3. Remove the sensor.
4. Visually check the sensor for chipping.
5. Check resistance between crankshaft position sensor (TDC) terminals ② and ③.

**Resistance: Approximately 1.2 - 1.5kΩ
[at 25°C (77°F)]**

If NG, replace crankshaft position sensor (TDC).






Glow Control System

When coolant temperature is lower than 75°C (167°F):

- Ignition switch ON
After ignition switch has been turned to ON, the glow relay turns ON for a period of time depending on engine coolant temperature, allowing current to flow through the glow plugs.
- Starting
After starting the engine, current will flow through the glow plugs for 300 seconds, or until the coolant temperature exceeds 50°C (122°F).



COMPONENT DESCRIPTION

Glow plug

The glow plug is provided with a ceramic heating element to obtain a high-temperature resistance. It glows in response to a signal sent from the ECM, allowing current to flow through the glow plug via the glow relay.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
83	<ul style="list-style-type: none"> ● Glow relay signal circuit is open or shorted. 	<ul style="list-style-type: none"> ● Harness or connectors (The glow relay signal circuit is open or shorted) ● Glow relay
98	<ul style="list-style-type: none"> ● Glow indicator lamp circuit is open or shorted. 	<ul style="list-style-type: none"> ● Harness or connectors (The glow indicator lamp circuit is open or shorted.) ● Glow lamp

Glow Control System (Cont'd)**DIAGNOSTIC TROUBLE CODE CONFIRMATION
PROCEDURE**

- 1) Turn ignition switch to "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 5 seconds.



OR



- 1) Turn ignition switch to "ON" position, and wait for at least 5 seconds.
- 2) Turn ignition switch off, wait for at least 5 seconds and then turn on.
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).




Glow Control System (Cont'd)

EC-GLOW-01



REFER TO THE FOLLOWING
 (M1) FUSE BLOCK - Junction Box (J/B)

**Glow Control System (Cont'd)
DIAGNOSTIC PROCEDURE**



INSPECTION START
(Glow relay signal circuit)

CHECK MAIN POWER SUPPLY.
Check power supply to ECCS-D relay.
Refer to "TROUBLE DIAGNOSIS FOR
POWER SUPPLY" (EC-CD-62).

A

CHECK POWER SUPPLY.

1. Turn ignition switch to the "LOCK" position.
2. Disconnect glow relay.
3. Turn ignition switch to the "ON" position.
4. Check voltage between glow relay connector terminals ①, ⑤ and ground with tester.

Voltage: Battery voltage

NG

Check the following:

- 15A fuse
- 80A fusible link
- Harness continuity between glow relay and fuse.

If NG, replace fuse or fusible link or repair harness or connectors.

OK

B

CHECK OUTPUT SIGNAL CIRCUIT.

1. Turn ignition switch to the "LOCK" position.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM connector terminal ⑤⑩ and glow relay connector terminal ②.

Continuity should exist.

If OK, check harness for short-circuit.

NG

Check harness connectors (F96), (E89)

Repair harness or connectors.

OK

CHECK GLOW PLUG AND GLOW RELAY.
Refer to "COMPONENT INSPECTION"
(EC-CD-129, 130).

NG

Replace glow plug or glow relay.

OK



Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed

Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END




Glow Control System (Cont'd)



```



    graph TD
        Start[INSPECTION START  
(Glow indicator lamp circuit)] --> A[A  
CHECK POWER SUPPLY CIRCUIT.  
1. Turn ignition switch to "LOCK" position.  
2. Disconnect combination meter harness connector.  
3. Turn ignition switch to "ON" position.  
4. Check voltage between combination meter harness connector terminal ⑤ and body ground.  
Voltage: Battery voltage]
        A -- NG --> NG_A[Check the following:  
• Harness for open or short-circuit between combination meter and battery.  
• 10A fuse  
If NG, replace fuse or repair harness or connectors.]
        A -- OK --> B[B  
CHECK GROUND CIRCUIT.  
1. Turn ignition switch to "LOCK" position.  
2. Disconnect ECM harness connector.  
3. Check harness continuity between ECM connector terminal ⑳ and combination meter connector terminal ⑦.  
Continuity should exist.  
If OK, check harness for short-circuit.]
        B -- NG --> NG_B[Check the following:  
• Harness connectors ①⑤⑩, ①①④  
• Harness for open or short-circuit between ECM and combination meter.  
If NG, repair harness or connectors.]
        B -- OK --> C[CHECK GLOW INDICATOR LAMP.  
Make sure that glow indicator lamp is not burnt out.]
        C -- NG --> NG_C[Replace glow indicator lamp.]
        C -- OK --> D[Disconnect and reconnect harness connectors in the circuit. Then retest.]
        D -- Trouble is not fixed --> E[Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.]
        E --> End[INSPECTION END]
    
```

Glow Control System (Cont'd)



Glow Control System (Cont'd)
SYSTEM OPERATION CHECK

Set voltmeter between glow plug and engine body.




1. Pre-glow control system
 - a. Turn ignition switch to "ON" position.
 - b. Read voltage.

Voltage:

Battery voltage for an engine coolant temperature dependent time.

* Repeatedly turning the ignition switch to "ON" position and to "LOCK" position may change the pre-glow time.



2. After-glow system

Start engine and read voltage.

Voltage:


Battery voltage for 5* minutes

* Engine coolant temperature is lower than 50°C (122°F).

COMPONENT INSPECTION

Glow relay

1. Check relay for coil continuity between glow relay terminals ① and ②.
Continuity should exist.
2. Check relay for proper operation by applying 12V dc voltage between glow relay terminals ① and ② and checking continuity between terminals ③ and ⑤.



Coil voltage	Continuity ③ and ⑤	Contact point
0V	No	OFF
12V	Yes	ON

Glow Control System (Cont'd)



Glow plug

1. Remove glow plug connecting plate.
2. Check each glow plug for continuity.

Continuity should exist:

Approximately 0.5Ω [at 25°C (77°F)]

- If NG, replace glow plug.



3. Install glow plug connecting plate securely.
- **Do not bump glow plug heating element. If it is bumped, replace glow plug with new one. (If glow plug is dropped from a height of 0.1 m (3.94 in) or greater, replace with new one.)**
 - **If glow plug installation hole is contaminated with carbon, remove using a reamer or suitable tool.**
 - **Hand-tighten glow plug by turning it 2 to 3 times, then tighten using a tool to specified torque.**

 : 15 - 20 N·m (1.5 - 2.0 kg-m, 11 - 14 ft-lb)

Air Conditioner Cut Control

The Air Conditioner relay is controlled by the ECM. During the following conditions, the ECM will cut the power supply towards the air conditioner relay:

- Starting engine
- Quick acceleration from low speed
- Undershooting of idle speed
- High engine coolant temperature [above 107°C (225°F)].
- Malfunctioning of engine speed sensor, accelerator position sensor or vehicle speed sensor when engine speed is below 2,100 rpm.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
85	<ul style="list-style-type: none"> ● Air conditioner relay signal circuit is shorted. 	<ul style="list-style-type: none"> ● Harness or connectors (The air conditioner relay signal circuit is shorted). ● Air conditioner relay

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE





- 1) Turn ignition switch and air conditioner switch to the "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 2 seconds.

OR



- 1) Turn ignition switch and air conditioner switch to the "ON" position.
- 2) Turn ignition switch to the "LOCK" position, wait at least 5 seconds and then turn to the "ON" position.
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

Air Conditioner Cut Control (Cont'd)




```

    graph TD
        Start[INSPECTION START  
(Air conditioner relay signal circuit)] --> A[A]
        A[CHECK POWER SUPPLY.  
1. Turn ignition switch to "LOCK" position.  
2. Disconnect air conditioner relay harness connector.  
3. Turn ignition switch to "ON" position.  
4. Check voltage between air conditioner relay connector terminals ②, ⑤ and engine ground.  
Voltage: Battery voltage] -- NG --> NG_A[Check the following:  
• Harness and connectors for open or short-circuit between ignition switch and air conditioner relay.  
• 10A fuse  
If NG, replace or repair the parts affected.]
        A -- OK --> B[B]
        B[CHECK GROUND CIRCUIT.  
1. Turn ignition switch to "LOCK" position.  
2. Disconnect ECM harness connector.  
3. Check harness continuity between ECM harness connector terminal ②⑧ and air conditioner relay harness connector terminal ①.  
Continuity should exist.  
If OK, check harness for short-circuit.] -- NG --> NG_B[Check the following:  
• Harness connectors E43, F2  
• Harness for open or short-circuit between ECM and air conditioner relay.  
If NG, repair harness or connectors.]
        B -- OK --> C[CHECK AIR CONDITIONER RELAY.  
Refer to HA section for inspection.]
        C -- NG --> NG_C[Replace air conditioner relay.]
        C -- OK --> D[Disconnect and reconnect harness connectors in the circuit. Then retest.]
        D -- Trouble is not fixed --> E[Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.]
        E --> End[INSPECTION END]
    
```

EGRC-Solenoid Valve


SYSTEM DESCRIPTION



The ECM receives signals sent from the engine coolant temperature sensor, crankshaft position sensor (TDC), atmospheric pressure sensor, mass air flow sensor and air conditioner switch to determine engine speed and operating conditions. Based on these signals, the ECM controls the EGR control solenoid valve operation.

No EGR operation will take place when the engine coolant temperature is below 70°C (158°F), when idling, at starting and during a period of time after starting the engine (70 - 200 seconds, depending on engine coolant temperature).

Engine coolant temperature °C (°F)	Load	EGRC-solenoid valve	EGR valve	Amount of EGR gas
Below 70 (158)	Any	OFF (Closed)	Fully closed	—
Above 70 (158)	Low load	ON (Open)	Fully open	Large
	High load	OFF (Closed)	Fully closed	—



COMPONENT DESCRIPTION

The EGR control solenoid valves control vacuum pressure acting on the EGR valve. The EGR control valve will then be fully opened or fully closed, as required.

Thus, intake air passages are opened or closed in relation to exhaust gas and intake air. Utilizing the relationship between exhaust gas pressure and intake air pressure control, the amount of EGR (exhaust gas recirculated) is regulated in large or small volumes.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
86	<ul style="list-style-type: none"> EGRC-solenoid valve A circuit is shorted. 	<ul style="list-style-type: none"> Harness or connectors (EGRC-solenoid valve A circuit is open or shorted). EGRC solenoid valve A

EGRC-Solenoid Valve (Cont'd)**DIAGNOSTIC TROUBLE CODE CONFIRMATION
PROCEDURE**

- 1) Turn ignition switch to the "ON" position.
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 2 seconds.





OR





- 1) Turn ignition switch to the "ON" position and wait at least 2 seconds.
- 2) Turn ignition switch to the "LOCK" position, wait at least 5 seconds and then turn to the "ON" position.
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results).

EGRC-Solenoid Valve (Cont'd)

EC-EGRC/V-01



**EGRC-Solenoid Valve (Cont'd)
DIAGNOSTIC PROCEDURE**



INSPECTION START
(Circuit for EGRC-solenoid valve A)

CHECK MAIN POWER SUPPLY.
Refer to Trouble Diagnosis for main power supply (EC-CD-62)

A
CHECK POWER SUPPLY.
1. Turn ignition switch to the "LOCK" position.
2. Disconnect EGRC-solenoid valve A harness connector.
3. Turn ignition switch to the "ON" position.
4. Check voltage between connector terminal ② and engine ground.
Voltage: Battery voltage

NG → Check the following:
● Harness continuity between ECCS-D relay and EGRC-solenoid valve A connector.
If NG, repair harness or connectors.

B
CHECK OUTPUT SIGNAL CIRCUIT.
1. Turn ignition switch to the "LOCK" position.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM harness connector terminal ②⑤ and EGRC solenoid valve A connector terminal ①.
Continuity should exist.
If OK, check harness for short-circuit.

NG → Check the following:
● Harness for open or short-circuit between ECM and solenoid valve.
If NG, repair harness or connectors.

CHECK COMPONENTS
(EGRC-solenoid valve).
Refer to "COMPONENT INSPECTION" EC-CD-140.



NG → Replace malfunctioning component(s).

Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed
Check ECM pin terminals for damage or the connection of ECM harness connector. Reconnect ECM harness connector and retest.

INSPECTION END

**EGRC-Solenoid Valve (Cont'd)
DIAGNOSTIC PROCEDURE**



INSPECTION START
EGR CONTROL OPERATION

A

CHECK OVERALL FUNCTION.

1. Start engine and warm it up sufficiently. (Air conditioner is "OFF").
2. Perform diagnostic test mode II (Self-diagnostic results). Make sure that diagnostic trouble code No. 55 is displayed.
3. Make sure that EGR diaphragm moves up and down (Use your finger or a suitable tool) under the following conditions:

At idle:
Spring does not move.

Racing engine from idle to 2800 rpm:
Spring moves up and down.

OK → INSPECTION END

NG

B

CHECK VACUUM SOURCES TO EGR VALVE.

1. Disconnect vacuum hoses to EGR valve.
2. Make sure that vacuum exists under the following conditions:

At idle:
Vacuum should not exist.

Racing engine from idle to 2800 rpm:
Vacuum should exist.

OK → CHECK COMPONENTS (EGR valve). (See page EC-CD-140.)

NG → Replace malfunctioning component(s).





NG
Ⓐ

EGRC-Solenoid Valve (Cont'd)

C

ACTIVE TEST	
EGR SOL/V A	OFF
MONITOR	
CKPS-RPM(TDC)	0rpm

C2ESA01



EGRC-Solenoid Valve (Cont'd)


COMPONENT INSPECTION

EGR valve

Apply vacuum to EGR vacuum port with a hand vacuum pump.


EGR valve spring should lift.

If NG, replace EGR valve.



EGRC-solenoid valve

Check air passage continuity.



Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.


Brake Switch

The ECM receives signals from two brake switches. One is a conventional brake lamp switch, the other is referred to as a redundant (RDNT) brake switch.


In case the accelerator pedal does not return to the idle position (pedal sticks), the driver will react by depressing the brake. In this (emergency) situation, the ECM will disregard the accelerator pedal signal and bring back the engine speed to 1200 rpm.

Diagnostic Trouble Code No.	Malfunction is detected when ...	Check Items (Possible Cause)
87	<ul style="list-style-type: none"> ● Brake switch circuits are open or shorted. 	<ul style="list-style-type: none"> ● Harness or connectors (Brake switch circuits are open or shorted.) ● Stop lamp switch ● RDNT brake switch

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE




- 1)  Turn ignition switch to "ON" position and select "DATA MONITOR" mode with CONSULT-II.
- 2) Depress brake pedal for at least 1 minute.

OR




- 1)  Turn ignition switch to "ON" position.
- 2) Depress brake pedal for at least 1 minute.
- 3) Turn ignition switch to "LOCK" position, wait at least 5 seconds and then turn to "ON" position.
- 4) Perform "Diagnostic Test Mode II" (Self-diagnostic results).


Brake Switch (Cont'd)

EC-BRK/SW-01



Brake Switch (Cont'd)





**Brake Switch (Cont'd)
COMPONENT INSPECTION**

Stop lamp switch and RDNT brake switch

1. Turn ignition switch to "LOCK" position.
2. Disconnect switch harness connectors.
3. Check continuity between terminals ① and ②.

Continuity:

Brake pedal	Stop lamp switch	RDNT brake switch
Released	No	No
Depressed	Yes	Yes

If NG, replace stop lamp switch or RDNT brake switch.

ECCS-D Relay

The ECCS-D Relay shuts off the main power supply to the ECM within 5 seconds after the ignition switch has turned to the "LOCK" position.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
92	<ul style="list-style-type: none"> ● ECCS-D relay shut-off time is too late. 	<ul style="list-style-type: none"> ● Harness or connectors (The ECCS-D relay circuit is shorted). ● ECCS-D relay ● ECM

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch to the "ON" position and select "DATA MONITOR" mode with CONSULT-II.
- 2) Turn ignition switch to the "LOCK" position and wait at least 5 seconds.
- 3) Turn ignition switch to the "ON" position and wait at least 2 seconds.

OR



- 1) Turn ignition switch to the "ON" position.
- 2) Turn it to the "LOCK" position, wait at least 5 seconds.
- 3) Turn ignition switch to the "ON" position and perform "Diagnostic Test Mode II" (Self-diagnostic results).

DIAGNOSTIC PROCEDURE

Refer to "Trouble Diagnosis for Power Supply" (EC-CD-62) for ECCS-D relay circuit inspection.

MI & Data Link Connectors

Malfunction indicator (MI) circuit is monitored for open or short-circuit. If the circuit is malfunctioning, MI can not report it but CONSULT-II can.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
97	<ul style="list-style-type: none"> ● MI circuit is open or shorted. 	<ul style="list-style-type: none"> ● Harness or connectors (MI circuit is open or shorted). ● MI lamp ● ECM

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch to "ON" position and select "DATA MONITOR" mode with CONSULT-II.
- 2) Start engine and run it for at least 2 seconds at idle speed.

OR






OVERALL FUNCTION CHECK

- 1) Turn ignition switch to "ON" position.
- 2) Check that MI lits on.

MI & Data Link Connectors (Cont'd)

EC-MIL-01






REFER TO THE FOLLOWING

(M1) FUSE BLOCK - Junction Box (J/B)

YEC320

MI & Data Link Connectors (Cont'd)
DIAGNOSTIC PROCEDURE



INSPECTION START
(MI circuit)

A
CHECK MI BULB.
1. Turn ignition switch to "LOCK" position.
2. Disconnect combination meter harness connector.
3. Apply battery voltage between combination meter terminal ⑤ and ⑬.
4. Check that MI lights on.

NG → Replace MI bulb.

B
CHECK POWER SUPPLY.
1. Turn ignition switch to "ON" position.
2. Check voltage between combination meter terminal ⑤ and body ground.
Voltage: Battery voltage

NG → Check the following:
● Harness for open or short-circuit between combination meter and ignition switch.
● 10A fuse
If NG, repair or replace harness or fuse.

C
CHECK GROUND CIRCUIT.
1. Turn ignition switch to "LOCK" position.
2. Disconnect ECM harness connector.
3. Check continuity between combination meter connector terminal ⑬ and ECM connector terminal ⑳.
Continuity should exist.
If OK, check harness for short-circuit.

NG → Check the following:
● Harness connectors ⑮⑩, ⑱④
If NG, repair harness or connectors.
● Harness and connectors for open or short-circuit between ECM and combination meter.


Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed
Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.


INSPECTION END

Start Signal

EC-S/SIG-01



: Detectable line for DTC
 : Non-detectable line for DTC



REFER TO THE FOLLOWING




- (M1) FUSE BLOCK - Junction Box (J/B)
- (E104) FUSE BLOCK - Junction Box (J/B)

**Start Signal (Cont'd)
DIAGNOSTIC PROCEDURE**

A

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

C2DMM04



General Specifications

Unit : rpm

Engine		CD20T
Maximum engine speed		5,400
Idle speed	A/C ON	825 ± 25
	A/C OFF	825 ± 25

Pump numbers

Engine	Part number	Pump assembly number
CD20T	16700 2J620	NP-VE4/ 10E2200L736

Pump data is not yet available.
Refer to CALIBRATION STANDARD published by BOSCH.)

Injection Nozzle

INSPECTION AND ADJUSTMENT

Injection nozzle assembly

Unit: kPa (bar, kg/cm², psi)

Initial injection pressure		
New		14,423 - 15,651 (144.2 - 156.5, 148 - 159, 2,091 - 2,269)
		15,000 - 16,000 (150.0 - 160.0, 153 - 163, 2,175 - 2,320)
Used		

Inspection and Adjustment

Plunger lift (Injection timing)	mm (in)	0.89 ± 0.08 at plunger lift timing mark
------------------------------------	---------	--

ELECTRIC GOVERNOR

Resistance [at 25°C (77°F)] Ω	1.0
-------------------------------	-----

MASS AIR FLOW SENSOR

Supply voltage	V	5.0V
Output voltage	V	1.9 - 2.3*

*: Engine is warmed up sufficiently and idling under no-load.

CRANKSHAFT POSITION SENSOR (TDC)

Resistance [at 25°C (77°F)] Ω	Approximately 1,215 - 1,485
-------------------------------	-----------------------------

ENGINE COOLANT TEMPERATURE SENSOR

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

GLOW PLUG

Resistance [at 25°C (77°F)] Ω	0.5
-------------------------------	-----

CONTROL SLEEVE POSITION SENSOR

Resistance [at 25°C (77°F)] Ω	6.0
-------------------------------	-----

ACCELERATOR POSITION SENSOR

Throttle valve conditions	Resistance kΩ [at 25°C (77°F)]
Completely closed	Approximately 1.2
Partially open	1.2 - 1.9
Completely open	Approximately 1.9

INJECTION TIMING CONTROL VALVE

Resistance [at 25°C (77°F)] Ω	Approximately 15
-------------------------------	------------------

FUEL TEMPERATURE SENSOR

Temperature °C (°F)	Resistance kΩ
25 (77)	Approximately 1.9

NOTE